

mitsubishi

ENGINE 4G9 SERIES (E-W)

WORKSHOP MANUAL

FOREWORD

This Workshop Manual contains procedures for removal, disassembly, inspection, adjustment, reassembly and installation, etc. for service mechanics.

All information, illustrations and product descriptions contained in this manual are current as at the time of publication. We, however, reserve the right to make changes at any time without prior notice or obligation.

Engine **11A**

FILING INSTRUCTION

Please keep these manual pages in the binder No. BN940001.

File these pages according to the signs "Added", "Revised" and "Deleted" on the "List of effective pages" which are interpreted below.

Added:

File the pages with this sign additionally in your manual.

Revised, Deleted:

Replace the existing pages with the corresponding pages with this sign.

Missing sheets will be supplied upon request.

 **MITSUBISHI MOTORS CORPORATION**

Pub. No. PWEE9502-G

INTRODUCTION

EXPLANATION OF MANUAL CONTENTS

Maintenance and Servicing Procedures

- (1) A diagram of the component parts is provided near the front of each section in order to give the reader a better understanding of the installed condition of component parts.
 - (2) The numbers provided within the diagram indicate the sequence for maintenance and servicing procedures.
N : Indicates a non-reusable part.
The tightening torque is provided where applicable.
- **Removal steps:**
The part designation number corresponds to the number in the illustration to indicate removal steps.
 - **Disassembly steps:**
The part designation number corresponds to the number in the illustration to indicate disassembly steps.
 - **Installation steps:**
Specified in case installation is impossible in reverse order of removal steps. Omitted if installation is possible in reverse order of removal steps.
 - **Reassembly steps:**
Specified in case reassembly is impossible in reverse order of disassembly steps. Omitted if reassembly is possible in reverse order of disassembly steps.

Classification of Major Maintenance/Service Points

When there are major points relative to maintenance and servicing procedures (such as essential maintenance and service points, maintenance and service standard values, information regarding the use of special tools, etc.), these are arranged together as major maintenance and service points and explained in detail.

-  : Indicates that there are essential points for removal or disassembly.
 : Indicates that there are essential points for installation or reassembly.

Symbols for Lubrication, Sealants and Adhesives

Information concerning the locations for lubrication and for application of sealants and adhesives is provided, by using symbols, in the diagram of component parts, or on the page following the component parts page, and explained.

-  : Grease (multipurpose grease unless there is a brand or type specified)
-  : Sealant or adhesive
-  : Brake fluid, automatic transmission fluid or air conditioner compressor oil
-  : Engine oil or gear oil

INTRODUCTION

Indicates the group title.

Indicates the section title.

Indicates the group number.

Indicates the section number.

Indicates the page number.

4G9 ENGINE (E-W) – Water Pump and Water Hose

11A-7-1


7. WATER PUMP AND WATER HOSE REMOVAL AND INSTALLATION <SOHC>

Denotes tightening torque.

Denotes non-reusable part.

This number corresponds to the number appearing in "Removal steps", "Disassembly steps", "Installation steps" or "Reassembly steps".

Operating procedures, cautions, etc. on removal, installation, disassembly and reassembly are described.



Removal steps

1. Water hose A
2. Water hose B
- ▶G▶ 3. Engine coolant temperature sensor
- ▶F▶ 4. Engine coolant temperature gauge unit
- ▶E▶ 5. Water outlet fitting
6. Water inlet fitting


- | | |
|-----|----------------------|
| ▶D▶ | 7. Thermostat |
| ▶C▶ | 8. Thermostat case |
| ▶B▶ | 9. O-ring |
| ▶B▶ | 10. Water inlet pipe |
| ▶B▶ | 11. O-ring |
| ▶A▶ | 12. Water pump |

INSTALLATION SERVICE POINTS

▶A▶ WATER PUMP INSTALLATION

- (1) Apply a 3 mm diameter of Form-In-Place Gasket (FIPG) to the location shown in the illustration.

Specified sealant:
Mitsubishi Genuine Part No. MD970389 or equivalent.



© Mitsubishi Motors Corporation

May 1995

PWEE9002

Issue date

Publication number-Revision code

LIST OF EFFECTIVE PAGES

Page	Revision Code	Date	Remarks	Page	Revision Code	Date	Remarks
11A-0-1	E	Dec. 1998		11A-6c-1a and 11A-6c-1b	G	May 2000	Added
11A-0-3	C	July 1997		11A-6c-2 to 11A-6c-5	E	Dec. 1998	
11A-0-4	G	May 2000	Revised	11A-6c-6 and 11A-6c-7	G	May 2000	Added
11A-0-5	G	May 2000	Added	11A-7-1	B	Nov. 1996	
11A-1-1 to 11A-1-6	G	May 2000	Revised	11A-7-2	G	May 2000	Revised
11A-1-6a and 11A-1-6b	G	May 2000	Revised	11A-7-3 to 11A-7-5	E	Dec. 1998	
11A-1-6c and 11A-1-6d	G	May 2000	Added	11A-8-1	G	May 2000	Revised
11A-1-7	E	Dec. 1998		11A-8-1a and 11A-8-1b	G	May 2000	Added
11A-1-8		May 1995		11A-8-2 and 11A-8-3	G	May 2000	Revised
11A-2-1 to 11A-2-3	A	Nov. 1995		11A-8-3a and 11A-8-3b	G	May 2000	Added
11A-3-1 and 11A-3-2	G	May 2000	Revised	11A-8-4	G	May 2000	Revised
11A-3-2a and 11A-3-2b	E	Dec. 1998		11A-8-5 and 11A-8-6	E	Dec. 1998	
11A-3-3 and 11A-3-4	A	Nov. 1995		11A-8-7 and 11A-8-8	G	May 2000	Revised
11A-3-5	G	May 2000	Revised	11A-8-9	E	Dec. 1998	
11A-3-6 and 11A-3-7	E	Dec. 1998		11A-8-10 to 11A-8-13	G	May 2000	Revised
11A-4-1	G	May 2000	Revised	11A-8-14 and 11A-8-15	G	May 2000	Added
11A-4-1a and 11A-4-1b	G	May 2000	Added	11A-8a-1 to 11A-8a-5	A	Nov. 1995	
11A-4-2	E	Dec. 1998		11A-8b-1 and 11A-8b-2	A	Nov. 1995	
11A-4-2a and 11A-4-2b	E	Dec. 1998		11A-9-1 and 11A-9-2		May 1995	
11A-4-2c and 11A-4-2d	G	May 2000	Revised	11A-9-3	A	Nov. 1995	
11A-4-2e and 11A-4-2f	G	May 2000	Added	11A-9-3a and 11A-9-3b	C	July 1997	
11A-4-3	A	Nov. 1995		11A-9-4 to 11A-9-8	A	Nov. 1995	
11A-4-4		May 1995		11A-9-9	C	July 1997	
11A-4-5 and 11A-4-6	A	Nov. 1995		11A-9-10	G	May 2000	Revised
11A-4-7 to 11A-4-9		May 1995		11A-9-11	C	July 1997	
11A-5-1	B	Nov. 1996		11A-9-12	A	Nov. 1995	
11A-5-2	F	July 1999	Revised	11A-10-1		May 1995	
11A-5-3 to 11A-5-6	E	Dec. 1998		11A-10-2	G	May 2000	Revised
11A-5a-1 to 11A-5a-3	G	May 2000	Revised	11A-10-3 and 11A-10-4	E	Dec. 1998	
11A-5a-4	G	May 2000	Added	11A-10-5 and 11A-10-6	G	May 2000	Revised
11A-6-1	B	Nov. 1996		11A-10-7	E	Dec. 1998	
11A-6-2	G	May 2000	Revised	11A-11-1		May 1995	
11A-6-2a and 11A-6-2b	G	May 2000	Added	11A-11-2	A	Nov. 1995	
11A-6-3 and 11A-6-4	B	Nov. 1996		11A-11-3 to 11A-11-6		May 1995	
11A-6a-1	G	May 2000	Revised	11A-11-7	G	May 2000	Revised
11A-6a-1a and 11A-6a-1b	G	May 2000	Added	11A-11-8		May 1995	
11A-6a-2	D	Jun. 1998		11A-12-1	G	May 2000	Revised
11A-6a-3 and 11A-6a-4	E	Dec. 1998		11A-12-1a and 11A-12-1b	G	May 2000	Revised
11A-6b-1	G	May 2000	Revised	11A-12-2	G	May 2000	Revised
11A-6b-1a and 11A-6b-1b	G	May 2000	Added	11A-12-3 and 11A-12-4	A	Nov. 1995	
11A-6b-2 and 11A-6b-3	E	Dec. 1998		11A-12-5 and 11A-12-6	G	May 2000	Revised
11A-6c-1	G	May 2000	Revised	11A-12-7	E	Dec. 1998	

Missing sheets will be supplied upon request.

ENGINE

4G9 SERIES

CONTENTS

GENERAL INFORMATION	11A-0-3
1. SPECIFICATIONS	11A-1-1
SERVICE SPECIFICATIONS	11A-1-1
REWORK DIMENSIONS	11A-1-4
TORQUE SPECIFICATIONS	11A-1-4
NEW TIGHTENING METHOD—BY USE OF BOLTS TO BE TIGHTENED IN PLASTIC AREA	11A-1-7
SEALANT	11A-1-7
FORM-IN-PLACE GASKET	11A-1-8
2. SPECIAL TOOLS	11A-2-1
3. ALTERNATOR AND IGNITION SYSTEM	11A-3-1
4. TIMING BELT	11A-4-1
5. FUEL AND EMISSION CONTROL SYSTEM	11A-5-1
5a. THROTTLE BODY AND EGR SYSTEM (GDI)	11A-5a-1
6. INTAKE AND EXHAUST MANIFOLD	11A-6-1
6a. INTAKE MANIFOLD (GDI)	11A-6a-1
6b. EXHAUST MANIFOLD (GDI)	11A-6b-1
6c. INJECTOR AND FUEL PUMP ASSEMBLY (GDI)	11A-6c-1
7. WATER PUMP AND WATER HOSE	11A-7-1
8. ROCKER ARMS AND CAMSHAFTS	11A-8-1
8a. ROCKER COVER AND CAMSHAFTS (MIVEC)	11A-8a-1
8b. ROCKER ARMS AND ROCKER SHAFT CAPS (MIVEC)	11A-8b-1
9. CYLINDER HEAD AND VALVES	11A-9-1
10. FRONT CASE AND OIL PUMP	11A-10-1
11. PISTON AND CONNECTING ROD	11A-11-1
12. CRANKSHAFT, CYLINDER BLOCK, FLYWHEEL AND DRIVE PLATE	11A-12-1

NOTES

GENERAL INFORMATION

4G92

Descriptions			4G92-SOHC	4G92-DOHC-MIVEC
Type			In-line OHV, SOHC	In-line OHV, DOHC
Number of cylinders			4	4
Combustion chamber			Pentroof type	Pentroof type
Total displacement dm ³			1,597	1,597
Cylinder bore mm			81.0	81.0
Piston stroke mm			77.5	77.5
Compression ratio			10.0	11.0
Valve timing	Intake valve	Opens (BTDC)	20°, 14°*	17° (Low-speed cam) 47.5° (High-speed cam)
		Closes (ABDC)	42°, 58°*	31° (Low-speed cam) 72.5° (High-speed cam)
	Exhaust valve	Opens (BBDC)	54°, 52°*	41° (Low-speed cam) 70° (High-speed cam)
		Closes (ATDC)	2°, 16°*	11° (Low-speed cam) 35° (High-speed cam)
Lubrication system			Pressure feed, full-flow filtration	Pressure feed, full-flow filtration
Oil pump type			Trochoid type	Trochoid type
Cooling system			Water-cooled forced circulation	Water-cooled forced circulation
Water pump type			Centrifugal impeller type	Centrifugal impeller type

*: LANCER for general export and CARISMA for 6B model

4G93

Descriptions			4G93-SOHC	4G93-DOHC	4G93-DOHC-GDI
Type			In-line OHV, SOHC	In-line OHV, DOHC	In-line OHV, DOHC
Number of cylinders			4	4	4
Combustion chamber			Pentroof type	Pentroof type	Pentroof type
Total displacement dm ³			1,834	1,834	1,834
Cylinder bore mm			81.0	81.0	81.0
Piston stroke mm			89.0	89.0	89.0
Compression ratio			10.0, 9.5	10.5	11.7* ¹ , 12.0* ²
Valve timing	Intake valve	Opens (BTDC)	14°	20°	15°
		Closes (ABDC)	50°	60°	56°
	Exhaust valve	Opens (BBDC)	58°	61°	55°
		Closes (ATDC)	10°	15°	15°
Lubrication system			Pressure feed, full-flow filtration	Pressure feed, full-flow filtration	Pressure feed, full-flow filtration
Oil pump type			Trochoid type	Trochoid type	Trochoid type
Cooling system			Water-cooled forced circulation	Water-cooled forced circulation	Water-cooled forced circulation
Water pump type			Centrifugal impeller type	Centrifugal impeller type	Centrifugal impeller type

*1: Up to 1999 model

*2: From 2000 model

4G94

Descriptions		4G94-DOHC-GDI	
Type		In-line OHV, DOHC	
Number of cylinders		4	
Combustion chamber		Pentroof type	
Total displacement dm ³		1,999	
Cylinder bore mm		81.5	
Piston stroke mm		95.8	
Compression ratio		10.6	
Valve timing	Intake valve	Opens (BTDC)	15°
		Closes (ABDC)	51°
	Exhaust valve	Opens (BBDC)	55°
		Closes (ATDC)	15°
Lubrication system		Pressure feed, full-flow filtration	
Oil pump type		Trochoid type	
Cooling system		Water-cooled forced circulation	
Water pump type		Centrifugal impeller type	

1. SPECIFICATIONS

SERVICE SPECIFICATIONS

Items		Standard value	Limit	
Timing belt				
Auto-tensioner rod protrusion amount (When removed from engine) mm		11	–	
Auto-tensioner rod stroke mm		Within 1	–	
Auto-tensioner rod protrusion amount (When checking with installed on engine) mm		3.8 – 4.5	–	
Rocker arms and camshaft				
Camshaft cam height mm	4G92-SOHC*1	Intake	37.34	36.84
		Exhaust	36.79	36.29
	4G92-SOHC*2	Intake	37.78	37.28
		Exhaust	37.83	37.33
	4G92-SOHC*3	Intake	36.92	36.42
		Exhaust	36.70	36.65
	4G93-SOHC	Intake	37.53	37.03
		Exhaust	37.64	37.14
	4G93-DOHC	Intake	35.31	34.81
		Exhaust	35.20	34.70
	4G93-DOHC-GDI	Intake	35.49	34.99
		Exhaust	34.73	34.23
	4G94-DOHC-GDI	Intake	35.49	34.99
		Exhaust	34.91	34.41
Valve clearance mm		Intake	0.09	–
		Exhaust	0.20	–
Camshaft journal O.D. mm		SOHC	26.0	–
		DOHC	45.0	–
Rocker cover and camshaft (MIVEC)				
Camshaft height mm		Intake A	36.41	36.91
		Intake B	33.58	33.08
		Exhaust A	35.83	35.33
		Exhaust B	34.24	33.74
Valve clearance (cold engine) mm		Intake	0.1	–
		Exhaust	0.2	–
Cylinder head and valve				
Cylinder head gasket surface flatness mm		Less than 0.03	0.2	
Grinding limit of cylinder head gasket surface mm		–	0.2*	
*Total resurfacing depth of both cylinder head and cylinder block				

*1: LANCER for Europe and CARISMA for Europe

*2: LANCER for general export and CARISMA for 6B model

*3: LANCER for Europe (from 2001 model) and CARISMA for Europe (from 2001 model)

Items			Standard value	Limit
Cylinder head overall height mm		SOHC	119.9 – 120.1	–
		DOHC	131.9 – 132.1	–
		DOHC–MIVEC	119.8 – 120.0	–
		DOHC–GDI	131.9 – 132.1	–
Thickness of valve head (margin) mm	SOHC	Intake	1.0	0.5
		Exhaust	1.3	0.8
	DOHC	Intake	1.0	0.5
		Exhaust	1.2	0.7
Valve overall height mm	SOHC	Intake	110.15	109.65
		Exhaust	113.70	113.20
	DOHC	Intake	104.19	103.69
		Exhaust	103.87	103.37
	DOHC–MIVEC	Intake	115.63	115.13
		Exhaust	115.63	115.13
	DOHC–GDI	Intake	104.19	103.69
		Exhaust	103.87	103.37
Valve spring free length mm		SOHC (Except from 2001 model vehicles for Europe)	50.9	49.9
		SOHC (From 2001 model vehicles for Europe)	49.5	48.5
		DOHC	45.0	44.0
		DOHC–MIVEC	51.5	50.5
		DOHC–GDI	44.8	43.8
Valve spring out-of-squareness			Max. 2°	4°
Valve stem to valve guide clearance mm	Except DOHC–GDI for PAJERO io	Intake	0.02 – 0.05	0.10
		Exhaust	0.05 – 0.09	0.15
	DOHC–GDI for PAJERO io	Intake	0.02 – 0.05	0.10
		Exhaust	0.04– 0.06	0.15
Valve seat valve contact width mm			0.9 – 1.3	–
Valve guide projection from cylinder head upper surface mm		SOHC	14.0	–
		DOHC	19.0	–
Valve stem projection mm	SOHC	Intake	49.30	49.80
		Exhaust	49.35	49.85
	DOHC	Intake	46.70	47.20
		Exhaust	46.65	47.15
	DOHC–MIVEC	Intake	58.13	58.63
		Exhaust	57.85	58.35
	DOHC–GDI	Intake	46.70	47.20
		Exhaust	46.65	47.15
Cylinder head bolt shank length mm			–	96.4

Items		Standard value	Limit
Valve stem O.D. mm		6.0	–
Valve face angle		45° – 45.5°	–
Valve spring load/installed height N/mm	SOHC	216/44.2	–
	DOHC	255/44.5	–
	DOHC–MIVEC	255/44.5	–
	DOHC–GDI	196/37.5	–
Valve guide I.D. mm		6.0	–
Font case, oil pump and oil pan			
Oil pump tip clearance mm		0.06 – 0.18	–
Oil pump side clearance mm		0.04 – 0.10	–
Oil pump body clearance mm		0.10 – 0.18	0.35
Piston and connecting rod			
Piston ring to piston ring groove clearance mm	No. 1	0.03 – 0.07	0.1
	No. 2	0.02 – 0.06	0.1
Piston ring end gap mm	No. 1	4G92, 4G93	0.25 – 0.40
		4G94	0.15 – 0.30
	No. 2		0.40 – 0.55
		Oil ring	SOHC
		DOHC	0.10 – 0.35
Crankshaft pin oil clearance mm		0.02 – 0.05	0.1
Piston pin press-in load N [Room temperature]		4,500 – 14,700	–
Connecting rod big end side clearance mm		0.10 – 0.25	0.4
Piston pin O.D. mm		19.0	–
Piston O.D. mm	4G92, 4G93	81.0	–
	4G94	81.5	–
Crankshaft, cylinder block, flywheel and drive plate			
Crankshaft journal oil clearance mm		0.02 – 0.04	0.1
Cylinder block gasket surface flatness mm		0.05	0.1
Grinding limit of cylinder block gasket surface mm *Total resurfacing depth of both cylinder head and cylinder block		–	0.2*
Cylinder block overall height mm	4G92	243.5	–
	4G93	263.5	–
	4G94	286.7	–
Cylinder block I.D. mm	4G92, 4G93	81.0	–
	4G94	81.5	–
Piston to cylinder clearance mm		0.02 – 0.04	–
Bearing cap bolt shank length mm		–	71.1
Crankshaft end play mm		0.05 – 0.25	0.4
Crankshaft journal O.D. mm		50	–
Crankshaft pin O.D. mm		45	–

REWORK DIMENSIONS

Items		Standard value	
Cylinder head and valve			
Oversize rework dimensions of valve guide hole (both intake and exhaust) mm	0.05 O.S.	11.05 – 11.07	
	0.25 O.S.	11.25 – 11.27	
	0.50 O.S.	11.50 – 11.52	
Oversize rework dimensions of intake valve seat hole mm	SOHC	0.30 O.S.	31.80 – 31.83
		0.60 O.S.	32.10 – 32.13
	DOHC	0.30 O.S.	34.30 – 34.32
		0.60 O.S.	34.60 – 34.62
Oversize rework dimensions of exhaust valve seat hole mm	SOHC	0.30 O.S.	29.30 – 29.32
		0.60 O.S.	29.60 – 29.62
	DOHC	0.30 O.S.	30.80 – 30.82
		0.60 O.S.	31.10 – 31.13
Crankshaft, flywheel and drive plate			
Crankshaft out of roundness and taper of journal and pin mm		0.005	

NOTE

O.D.: Outer diameter

I.D.: Inner diameter

O.S.: Oversize diameter

TORQUE SPECIFICATIONS

Items	Nm
Alternator and ignition system	
Oil level gauge	13
Distributor	12
Ignition coil	10
Spark plug	25
Crankshaft bolt	181
Alternator brace (M8)	23
Alternator brace (M10)	49
Lock bolt	23
Adjusting bolt <Except SOHC for PAJERO io and DOHC-GDI for PAJERO io>	10
Adjusting bolt <SOHC-PAJERO io and DOHC-GDI for PAJERO io>	4.9
Power steering pump pulley	25
Power steering pump bracket stay	49
Power steering pump bracket (M8)	21
Power steering pump bracket (M10)	44
Alternator pivot bolt	44
Center cover	3

Items	Nm
Ignition failure sensor (M6)	5
Ignition failure sensor (M8)	23
Cam position sensor	9
Cam position sensor support	13
Cam position sensing cylinder	21
Engine cover	2.9
Timing belt	
Camshaft sprocket bolt	88
Cam position sensor <DOHC>	9.8
Crank angle sensor	9.8
Timing belt rear cover	11
Timing belt tensioner	24
Engine support bracket, right	49
Accessory mount	49
Timing belt cover	11
Tensioner pulley bolt	49
Tensioner arm bolt	44
Auto-tensioner bolt	13
Idler pulley bolt	36
Fuel system and emission system	
Breather tube	21
Fuel pump	18
Carburetor	17
EGR valve	21
Fuel return pipe	9
Delivery pipe	12
Fuel pressure regulator	9
Throttle body stay	23
Throttle body	19
Vacuum hose and pipe assembly <SOHC-MPI for other than PAJERO io>	10
Vacuum hose and pipe assembly <SOHC-MPI for PAJERO io>	9
Solenoid valve assembly <SOHC-MPI for other than PAJERO io>	11
Solenoid valve assembly <SOHC-MPI for PAJERO io>	9
Throttle body and EGR system (GDI)	
Air intake resonator	9
Intake manifold stay (M8)	20
Intake manifold stay (M10)	30
Water hose clamp	13

Items	Nm
Water pipe	11
Throttle body	18
Throttle body stay	24
EGR valve (Washer)	18
EGR valve (Flange)	24
Engine hanger	18
EGR valve support bolt	18
EGR valve support nut	23
Air by-pass valve	9
Intake manifold and exhaust manifold	
Exhaust manifold (M8)	18
Exhaust manifold (M10)	29
Exhaust manifold bracket (M8)	19
Exhaust manifold bracket (M10)	35
Engine hanger	12
Oil level gauge guide	14
Boost sensor	5
Intake air temperature sensor	13
Heat protector	13
Intake manifold	20
Intake manifold stay	30
Oxygen sensor	44
Intake manifold (GDI)	
Vacuum pipe and hose <Except for PAJERO io>	11
Vacuum pipe and hose <For PAJERO io>	9
Solenoid valve	9
Fuel pump protector	23
Connector bracket	11
Branch tube (M6 x 14)	11
Branch tube (M6 x 18)	9
Intake manifold stay	30
Accelerator cable bracket	9
Vacuum pipe	11
Intake manifold	19
Exhaust manifold (GDI)	
Oil level gauge guide	13
Exhaust manifold cover	13
Engine hanger bolt	24

Items	Nm
Engine hanger nut (M8)	18
Engine hanger nut (M10)	29
Exhaust manifold bracket (M8 × 20)	18
Exhaust manifold bracket (M8 × 22)	35
Exhaust manifold bracket (M8 × 25)	19
Exhaust manifold bracket (M10)	35
Exhaust manifold bracket (For PAJERO io)	98
Exhaust manifold (M8)	17
Exhaust manifold (M10)	29
Injector and fuel pump assembly (GDI)	
Fuel low pressure pipe (M6)	18
Fuel low pressure pipe (M8)	9
Fuel nipple	9
Clamp	9
Fuel feed pipe	11
Fuel pump	17
Harness bracket	11
Fuel pipe	11
Fuel return pipe	11
Fuel return pipe clamp	9
Fuel high pressure regulator	18
Fuel pressure sensor <Except for PAJERO io>	23
Fuel pressure sensor <For PAJERO io>	18
Spacer	18
Pump camshaft case	23
Injector holder	22
Delivery pipe and injector	11
Water pump and water hose	
Water pump	24
Water inlet pipe	14
Thermostat case	24
Water inlet fitting <Except DOHC-GDI for PAJERO io>	19
Water inlet fitting <DOHC-GDI for PAJERO io>	23
Water by-pass fitting	23
Water pipe	13
Water outlet fitting <Except DOHC-GDI for PAJERO io>	14
Water outlet fitting <DOHC-GDI for PAJERO io>	23
Engine coolant temperature gauge unit	10

Items	Nm
Engine coolant temperature sensor	29
Water fitting	23
Rocker arms and camshaft	
Lock nut	9
Rocker arm shaft	31
Harness bracket	10
Rocker cover	3.5
Bearing cap bolt (M6)	11
Bearing cap bolt (M8)	24
Beam camshaft cap (M6)	11
Beam camshaft cap (M8)	21
Rocker cover and camshafts (MIVEC)	
Rocker cover	4
Oil pump	11
Arm spring holder	11
Camshaft bearing cap (M6)	11
Camshaft bearing cap (M8)	23
Oil control valve	9
Rocker arms and rocker shaft caps (MIVEC)	
Rocker shaft cap	11
Cylinder head and valves	
Cylinder head bolt	74 Nm and then completely loosen, finally tighten 20 Nm + 90° + 90°
Oil pressure switch	10
Front case and oil pump	
Oil pump cover	10
Oil pump case	14
Relief plug	44
Oil screen	19
Oil pan	7
Upper oil pan <Only M6 × 121>	7
Upper oil pan <Except M6 × 121>	11
Upper oil pan <M8>	24
Lower oil pan	7
Cover	7
Baffle plate <For CARISMA, SPACE STAR, GALANT>	7
Drain plug	39
Oil pressure switch	10
Baffle plate mounting bolt	7

Items	Nm
Piston and connecting rod	
Connecting rod cap nut	20 + 90° to 100°
Crankshaft, cylinder block, flywheel and drive plate	
Bearing cap bolt	25 + 90° to 100°
Oil seal case	11
Bell housing cover	9
Rear plate	11
Drive plate bolt	98
Flywheel bolt	98
Baffle plate	9
Knock sensor	22

Intentionally blank

NEW TIGHTENING METHOD – BY USE OF BOLTS TO BE TIGHTENED IN PLASTIC AREA

A new type of bolts, to be tightened in plastic area, is currently used for some parts of the engine. The tightening method for bolts of this type is different from the conventional one. Be sure to observe the method described in the text when tightening the bolts.

Service limits are provided for the bolts. Make sure that the service limits described in the text are strictly observed.

- Areas where the bolts are in use:

- (1) Cylinder head bolts
- (2) Main bearing cap bolts
- (3) Connecting rod cap bolts

- Tightening method

After tightening the bolts to the specified torque, tighten them another 90° or 180° (twice 90°). The tightening method varies on different areas. Observe the tightening method described in the text.

SEALANT

Items	Specified sealant	Quantity
Water pump	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Thermostat case	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Water by-pass fitting	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Water fitting	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Engine coolant temperature sensor	3M Nut Locking Part No.4171 or equivalent	As required
Engine coolant temperature gauge unit	3M ATD Part No.8660 or equivalent	As required
Camshaft bearing cap	3M ATD Part No.8660 or equivalent	As required
Semi-circular packing	3M ATD Part No.8660 or equivalent	As required
Rocker cover	3M ATD Part No.8660 or equivalent	As required
Beam camshaft cap	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Cylinder head	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Oil pressure switch	3M ATD Part No.8660 or equivalent	As required
Water outlet fitting	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Oil pump case	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Oil pan/Upper oil pan/Lower oil pan	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Oil seal case	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Drive plate bolt	3M Nut Locking Part No.4171 or equivalent	As required
Flywheel bolt	3M Nut Locking Part No.4171 or equivalent	As required
Cam position sensor support	Mitsubishi Genuine Part No.MD970389 or equivalent	As required
Oil control valve	3M ATD Part No.8660 or equivalent	As required
Camshaft holder	3M ATD Part No.8660 or equivalent	As required

FORM-IN-PLACE GASKET

The engine has several areas where the form-in-place gasket (FIPG) is in use. To ensure that the gasket fully serves its purpose, it is necessary to observe some precautions when applying the gasket. Bead size, continuity and location are of paramount importance. Too thin a bead could cause leaks. Too thick a bead, on the other hand, could be squeezed out of location, causing blocking or narrowing of the fluid feed line. To eliminate the possibility of leaks from a joint, therefore, it is absolutely necessary to apply the gasket evenly without a break, while observing the correct bead size.

The FIPG used in the engine is a room temperature vulcanization (RTV) type and is supplied in a 100-gram tube (Part No. MD970389 or MD997110). Since the RTV hardens as it reacts with the moisture in the atmospheric air, it is normally used in the metallic flange areas. The FIPG, Part No. MD970389, can be used for sealing both engine oil and coolant, while Part No. 997110 can only be used for engine oil sealing.

Disassembly

The parts assembled with the FIPG can be easily disassembled without use of a special method. In some cases, however, the sealant between the joined surfaces may have to be broken by lightly striking with a mallet or similar tool. A flat and thin gasket scraper may be lightly hammered in between the joined surfaces. In this case, however, care must be taken to prevent damage to the joined surfaces. For removal of the oil pan, the special tool "Oil Pan Remover" (MD998727) is available. Be sure to use the special tool to remove the oil pan. <Except aluminium die-cast oil pans>

Surface Preparation

Thoroughly remove all substances deposited on the gasket application surfaces, using a gasket scraper or wire brush. Check to ensure that the surfaces to which the FIPG is to be applied is flat. Make sure that there are no oils, greases and foreign substances deposited on the application surfaces. Do not forget to remove the old sealant remained in the bolt holes.









Form-In-Place Gasket Application








When assembling parts with the FIPG, you must observe some precautions, but the procedure is very simple as in the case of a conventional pre-cut gasket.







Applied FIPG bead should be of the specified size and without breaks. Also be sure to encircle the bolt hole circumference with a completely continuous bead. The FIPG can be wiped away unless it is hardened. While the FIPG is still moist (in less than 15 minutes), mount the parts in position. When the parts are mounted, make sure that the gasket is applied to the required area only. In addition, do not apply any oil or water to the sealing locations or start the engine until a sufficient amount of time (about one hour) has passed after installation is completed.

The FIPG application procedure may vary on different areas. Observe the procedure described in the text when applying the FIPG.

2. SPECIAL TOOLS


Tool	Number	Name	Use
	MB990938	Handle	Use with MD998776
	MB990767	Crankshaft pulley holder	Holding camshaft sprocket when loosening and tightening of bolt. Use with MD998719
	MD998440	Leak-down tester	Leak-down test of lash adjuster
	MD998442	Air bleed wire	Air bleeding of lash adjuster
	MD998713	Camshaft oil seal installer	Installation of camshaft oil seal
	MD998716	Crankshaft wrench	Rotation of crankshaft when installing piston and timing belt.
	MD998717	Crankshaft front oil seal installer	Installation of crankshaft front oil seal
	MB991653	Cylinder head bolt wrench	Tightening and loosening of cylinder head bolt
	MB991659	Guide D	Removal of piston pin (Use with MD998780)

Tool	Number	Name	Use
	MD998719	Pulley holder pin (2)	Use with MB990767
	MD998727	Oil pan remover	Removal of the oil pan
	MD998754	Pin	Use with MB990767
	MD998767	Tensioner pulley socket wrench	Adjustment of timing belt tension
	MD998772	Valve spring compressor	Removal and installation of valve and related parts
	MD998774	Valve stem seal installer	Installation of valve stem seal
	MD998775	Valve stem seal installer	Installation of valve stem seal
	MD998776	Crankshaft rear oil seal installer	Installation of crankshaft rear oil seal Use with MB99038

Tool	Number	Name	Use
	MD998780	SETTING TOOL Piston pin	Removal and installation of piston pin
	MD998735	Valve spring compressor	Compression of valve spring
	MD998781	Flywheel stopper	Holding flywheel and drive plate
	MB991477	Valve adjusting wrench	Adjustment of valve clearance (MIVEC)
	MB991478	Valve adjusting wrench feeler gauge set	Adjustment of valve clearance (MIVEC)
	MB991479	Rocker arm piston checker	Adjustment of valve clearance (MIVEC)
	MD998784	Valve spring compressor adapter	Compression of valve spring (MIVEC) (Use with MD998772)

3. ALTERNATOR AND IGNITION SYSTEM

REMOVAL AND INSTALLATION <SOHC> (Engines with distributor)



9EN0564

Removal steps

1. Drive belt*
2. Alternator
3. Alternator brace
4. Crankshaft bolt
5. Crankshaft pulley




6. Flange
7. Spark plug cable
8. Spark plug
9. O-ring
10. Distributor

NOTE:

*: For details of adjustment, refer to the relevant model's chassis workshop manual.

**REMOVAL AND INSTALLATION <SOHC for other than PAJERO io>
(Engines without distributor)**



9EN1053

Removal steps

- 1. Drive belt*
- 2. Alternator
- 3. Alternator brace
- 4. Crankshaft bolt
- 5. Crankshaft pulley
- 6. Front flange
- 7. Spark plug cable
- 8. Ignition coil
- 9. Spark plug




- 10. Ignition failure sensor (From 2001 model vehicles for Europe)
- 11. Cam position sensor
- 12. Cam position sensor support
- 13. Cam position sensing cylinder



NOTE:

*: For details of adjustment, refer to the relevant model's chassis workshop manual.

**REMOVAL AND INSTALLATION <SOHC for PAJERO io>
(Engines without distributor)**



9EN0273

Removal steps

1. Drive belt*
2. Alternator
3. Alternator brace
4. Crankshaft bolt
5. Crankshaft pulley
6. Front flange



7. Spark plug cable
8. Ignition coil
9. Spark plug
10. Cam position sensor
11. Cam position sensor support
12. Cam position sensing cylinder




NOTE:

*: For details of adjustment, refer to the relevant model's chassis workshop manual.

Intentionally blank

REMOVAL AND INSTALLATION <DOHC>



9EN0565

Removal steps

1. Drive belt*
2. Alternator
3. Alternator brace
4. Crankshaft bolt
5. Crankshaft pulley
6. Flange




7. Center cover
8. Ignition coil
9. Spark plug cable
10. Spark plug
11. Ignition failure sensor

NOTE:

*: For details of adjustment, refer to the relevant model's chassis workshop manual.

REMOVAL AND INSTALLATION <DOHC-MIVEC>



9EN0710

Removal steps

- 1. Drive belt
- 2. Alternator
- 3. Alternator brace
- 4. Crankshaft bolt
- 5. Crankshaft pulley
- 6. Front flange



- 7. Center cover
- 8. Spark plug cable
- 9. Ignition coil
- 10. Spark plug
- 11. Cam position sensor
- 12. Cam position sensor support
- 13. Cam position sensing cylinder




NOTE:

*: For details of adjustment, refer to the relevant model's chassis workshop manual.

REMOVAL AND INSTALLATION

<DOHC-GDI for CARISMA, SPACE STAR, SPACE RUNNER, GALANT>



9EN1054

Removal steps

- 1. Drive belt*
- 2. Alternator
- 3. Alternator brace
- 4. Crankshaft bolt
- 5. Crankshaft pulley
- 6. Front flange
- 7. Engine cover
- 8. Earth strap (From 2001 model for CARISMA, From 2001 model for SPACE STAR)
- 9. Ignition coil


- 10. Spark plug
- 11. Cam position sensor
- 12. Cam position sensor support
- 13. Cam position sensing cylinder
- 14. Ignition failure sensor (From 2001 model for CARISMA, From 2001 model for SPACE STAR)

NOTE:

*: For details of adjustment, refer to the relevant model's chassis workshop manual.



REMOVAL AND INSTALLATION <DOHC-GDI for PAJERO io>



9EN0954

Removal steps

1. Oil level gauge
2. Oil level gauge guide
3. O-ring
4. Drive belt*
5. Alternator
6. Alternator brace
7. Crankshaft bolt
8. Crankshaft pulley
9. Front flange




10. Power steering pump pulley
11. Power steering pump bracket stay
12. Power steering pump bracket
13. Ignition coil
14. Spark plug
15. Cam position sensor
16. Cam position sensor support
17. Cam position sensing cylinder




NOTE:

*: For details of adjustment, refer to the relevant model's chassis workshop manual.

**REMOVAL SERVICE POINT****◀A▶ CRANKSHAFT BOLT REMOVAL**


- (1) Use the special tool to hold the flywheel or the drive plate, and then loosen the crankshaft mounting bolts.

**INSTALLATION SERVICE POINTS****▶A◀ CAM POSITION SENSOR SUPPORT INSTALLATION**

- (1) Apply a 3 mm bead of form-in-place gasket (FIPG) to the area shown.

Specified sealant:


Mitsubishi Genuine Part No. MD970389 or equivalent.

**▶B◀ CRANKSHAFT BOLT INSTALLATION**

- (1) Use the special tool to hold the flywheel or the drive plate, and then tighten the crankshaft mounting bolts.

4. TIMING BELT

REMOVAL AND INSTALLATION <SOHC for CARISMA (Up to 1999 model), LANCER (Up to 2000 model), GALANT>



9EN0618

Removal steps


1. Timing belt front upper cover
2. Timing belt front lower cover
3. Engine support bracket, right
4. Timing belt
5. Tensioner spring
6. Timing belt tensioner
7. Timing belt rear cover

8. Crankshaft angle sensor
(Engines without distributor)
9. Crankshaft sprocket
10. Crankshaft spacer
(Engines without distributor)
11. Crankshaft sensing plate
(Engines without distributor)
12. Crankshaft key
13. Camshaft sprocket bolt
14. Camshaft sprocket



REMOVAL AND INSTALLATION

<SOHC for CARISMA (From 2000 model), LANCER (From 2001 model)>



Removal steps

1. Timing belt front upper cover
2. Timing belt front lower cover
3. Engine support bracket, right
4. Timing belt
5. Tensioner spring
6. Timing belt tensioner
7. Timing belt rear cover
8. Crankshaft angle sensor
(Engines without distributor)




9. Crankshaft sprocket
10. Crankshaft spacer
(Engines without distributor)
11. Crankshaft sensing plate
(Engines without distributor)
12. Crankshaft key
13. Camshaft sprocket bolt
14. Camshaft sprocket



Intentionally blank

REMOVAL AND INSTALLATION <SOHC for PAJERO io>



9EN0274


Removal steps

1. Timing belt front upper cover
2. Timing belt front lower cover
3. Accessory mount
4. Timing belt
5. Tensioner spring
6. Timing belt tensioner
7. Timing belt rear cover

8. Crankshaft angle sensor
9. Crankshaft sprocket
10. Crankshaft spacer
11. Crankshaft sensing plate
12. Crankshaft key
13. Camshaft sprocket bolt
14. Camshaft sprocket



REMOVAL AND INSTALLATION <DOHC>



Removal steps

- 1. Timing belt upper cover
- 2. Timing belt lower cover
- 3. Engine support bracket
- 4. Timing belt
- 5. Tensioner pulley
- 6. Tensioner arm
- 7. Shaft
- 8. Auto-tensioner
- 9. Timing belt rear cover
- 10. Idler pulley


◀A▶ ▶F◀

▶E◀

- 11. Cam position sensor
- 12. Crank angle sensor
- 13. Crankshaft sprocket
- 14. Sensing plate
- 15. Crankshaft spacer
- 16. Crankshaft sprocket key
- 17. Camshaft sprocket bolt
- 18. Camshaft sprocket
- 19. Timing belt rear cover
- 20. Timing belt rear cover

◀B▶ ▶A◀

REMOVAL AND INSTALLATION <DOHC-MIVEC>



9EN0619


Removal steps

- 1. Timing belt front upper cover
- 2. Timing belt front lower cover
- 3. Engine support bracket, right
- ◀A▶ ▶F▶ 4. Timing belt
- 5. Tensioner pulley
- 6. Tensioner arm
- 7. Shaft
- ▶E▶ 8. Auto tensioner
- 9. Timing belt rear cover
- 10. Idler pulley

- 11. Crankshaft angle sensor
- 12. Crankshaft sprocket
- 13. Crankshaft spacer
- 14. Crankshaft sensing plate
- 15. Crankshaft key
- ◀B▶ ▶A▶ 16. Camshaft sprocket bolt
- 17. Camshaft sprocket
- 18. Timing belt rear cover
- 19. Timing belt rear cover

REMOVAL AND INSTALLATION

<DOHC-GDI for CARISMA, SPACE STAR, SPACE RUNNER>




9EN1056

Removal steps

- | | |
|---|--|
| <p>1. Timing belt front upper cover
 2. Timing belt front lower cover
 3. Engine support bracket, right
 4. Timing belt
 5. Tensioner pulley
 6. Tensioner arm
 7. Shaft
 8. Auto tensioner
 9. Timing belt rear cover
 10. Idler pulley
 11. Crankshaft angle sensor (Up to 1999 model)
 12. Crankshaft angle sensor (From 2000 model)</p> | <p>13. Crankshaft sprocket
 14. Crankshaft spacer
 15. Crankshaft sensing plate
 16. Crankshaft key
 17. Camshaft sprocket bolt
 18. Camshaft sprocket
 19. Timing belt rear cover (Up to 2000 model)
 20. Timing belt rear cover (Up to 2000 model)
 21. Timing belt rear upper cover (From 2001 model)</p> |
|---|--|

REMOVAL AND INSTALLATION <DOHC-GDI for GALANT>




9EN1057

Removal steps

- 1. Timing belt front upper cover
- 2. Timing belt front lower cover
- 3. Engine support bracket, right
- ◀A▶ ▶F◀ 4. Timing belt
- 5. Tensioner pulley
- 6. Tensioner arm
- 7. Shaft
- ▶E◀ 8. Auto tensioner
- 9. Timing belt rear cover

- 10. Idler pulley
- 11. Crankshaft angle sensor
- 12. Crankshaft sprocket
- 13. Crankshaft spacer
- 14. Crankshaft sensing plate
- 15. Crankshaft key
- ◀B▶ ▶A◀ 16. Camshaft sprocket bolt
- 17. Camshaft sprocket
- 18. Timing belt rear upper cover

REMOVAL AND INSTALLATION <DOHC-GDI for PAJERO io>



Removal steps

- 1. Timing belt front upper cover
- 2. Timing belt front lower cover
- 3. Accessory mount
- 4. Timing belt
- 5. Tensioner pulley
- 6. Tensioner arm
- 7. Shaft
- 8. Auto tensioner
- 9. Timing belt rear cover
- 10. Idler pulley

- 11. Bracket
- 12. Crankshaft angle sensor
- 13. Crankshaft sprocket
- 14. Crankshaft sensing plate
- 15. Crankshaft spacer
- 16. Crankshaft key
- 17. Camshaft sprocket bolt
- 18. Camshaft sprocket
- 19. Timing belt rear cover
- 20. Timing belt rear cover

◀A▶ ▶F▶

▶E▶

◀B▶ ▶A▶

Intentionally blank

REMOVAL SERVICE POINTS





◀A▶ TIMING BELT REMOVAL

- (1) Mark belt running direction for reinstallation.

◀B▶ CAMSHAFT SPROCKET BOLT REMOVAL


<With rocker cover removed> (Except SOHC)

- (1) Use a wrench to hold the hexagonal part of the camshaft, and then remove the camshaft sprocket mounting bolt.




INSTALLATION SERVICE POINTS

▶A◀ CAMSHAFT SPROCKET BOLT INSTALLATION




►B◄ TIMING BELT TENSIONER INSTALLATION

- (1) Let the pulley of the timing belt tensioner come closest to the exhaust side. Temporarily tighten the tensioner pulley fixing bolt.



►C◄ TENSIONER SPRING INSTALLATION

- (1) Insert the tip A (shorter one) of the tensioner spring into the oil pump case.
- (2) Use pliers or similar tool to pinch the tip B (longer one), and then hook it to the tensioner bracket arm.




►D◄ TIMING BELT INSTALLATION

- (1) Turn the crankshaft sprocket by three teeth from the timing mark.


Caution


Aligning the timing marks positions the piston to the top dead centre. Then, if the camshaft turns, the valves may hit and damage the pistons.

- (2) Check that the timing belt tensioner and tensioner spring are installed correctly. (Refer to the service points B and C.)
- (3) Align the timing marks on the camshaft sprocket to that on the cylinder head.




- (4) Align the timing mark on the crankshaft sprocket to that on the oil pump case.
- (5) Place the timing belt over the sprocket according in the following order.
 1. Crankshaft sprocket
 2. Water pump sprocket
 3. Camshaft sprocket
 4. Tension pulley






- (6) Slightly loosen the tensioner pulley fixing bolt which is tightened temporarily to tighten the belt by a force of the tensioner spring.




- (7) Turn the crankshaft clockwise by two turns.
 (8) Check that the timing marks are aligned.
 (9) Tighten the fixing bolt of the tensioner pulley.




▶ E ◀ AUTO-TENSIONER INSTALLATION

- (1) If the auto-tensioner rod is fully extended, set it in the retracted position with the following procedure.
- 1) Hold the auto-tensioner in a vice, being careful not to tilt it.
 - 2) Slowly close the vice to force the rod in to align hole (A) of the rod with the set hole (B).
 - 3) Insert a 2.0-mm-Allen key in diameter or similar into the set holes.
 - 4) Remove the auto-tensioner from the vice.




- (2) Install the auto-tensioner
 Leave the align key until installation of the timing belt is completed.




►◀ TIMING BELT INSTALLATION


- (1) Make sure that the auto-tensioner is installed properly. (Refer to service point F.)
- (2) Align the timing mark on each sprocket with the corresponding mark on the timing belt.
- (3) Turn the crankshaft sprocket one half the tooth width counterclockwise.




- (4) Fit the timing belt to the intake camshaft sprocket and secure with a paper clip at the illustrated position.




- (5) Use two wrenches to fit the timing belt to the exhaust sprocket while aligning the timing marks.




- (6) Secure the timing belt with a paper clip at the illustrated position.



- (7) Fit the belt to the idler pulley water pump sprocket, crankshaft sprocket and tensioner pulley in that order.




- (8) Raise the tensioner pulley in the direction of an arrow and tighten the tensioner pulley bolt.
 (9) Remove the two paper clips.
 (10) Make sure that all timing marks are in alignment.
 (11) Give a 1/4 counterclockwise turn to the crankshaft. Then turn the crankshaft clockwise to align the timing marks again.




- (12) Install the special tool and a torque wrench to the tensioner pulley.
- (13) Using torque wrench, torque to 2.6 Nm.
- (14) While holding the tensioner pulley to prevent it from turning, tighten the center bolt to the specified torque.
- (15) Give two clockwise turns to the crankshaft and leave as it is for approx. 15 minutes.
- (16) Check if the Allen wrench inserted during installation of the auto-tensioner can be pulled out lightly. If it can be pulled out lightly, the belt is properly tensioned. Therefore, pull out the wrench. The belt is also properly tensioned if the auto-tensioner projection is of standard value.

Standard value: 3.8 – 4.5 mm



- (17) If the wrench cannot be pulled out lightly, repeat the steps (12) through (15) to obtain appropriate belt tension.




INSPECTION

11300200077


TIMING BELT

Replace belt if any of the following conditions exist.


- (1) Hardening of back rubber.
Back side is glossy without resilience and leaves no indent when pressed with fingernail.




- (2) Cracks on rubber back.
- (3) Cracks or peeling of canvas.
- (4) Cracks on tooth bottom.
- (5) Cracks on belt sides.



- (6) Abnormal wear of belt sides. The sides are normal if they are sharp as if cut by a knife.




- (7) Abnormal wear on teeth.
(8) Missing tooth.



TENSIONER PULLER, IDLER PULLEY


- (1) Check the pulley for smooth rotation, excessive play, abnormal noise. Replace it if necessary.



AUTO-TENSIONER

- (1) Check the tensioner for oil leaks. Replace it if necessary.
(2) Check the rod end for wear or damage. Replace the tensioner if necessary.
(3) Measure the rod projection length. If not within the standard value, replace the tensioner.

Standard value: 11 mm




- (4) Press the rod by a force of 98 to 196 N and measure the rod stroke. If not within the standard value, replace the tensioner.

Standard value: 1 mm or less

5. FUEL AND EMISSION CONTROL SYSTEM


REMOVAL AND INSTALLATION <SOHC-CARBURETOR>



Removal steps

1. Breather tube
2. Fuel hose
3. Fuel hose
4. Fuel pump
5. Gasket
6. Insulator
7. Gasket
8. Carburetor
9. Gasket
10. EGR valve
11. Gasket

REMOVAL AND INSTALLATION <SOHC-MPI for other than PAJERO iO>




9EN1027

Removal steps

- 1. Vacuum hose and pipe assembly
- 2. Throttle body
- ▶C◀ 3. Gasket
- 4. Vacuum hose
- 5. Fuel hose
- ▶B◀ 6. Fuel pressure regulator
- 7. O-ring
- 8. Delivery pipe and injector
- 9. Insulator

- ▶A◀ 10. Insulator
- 11. Injector
- 12. O-ring
- 13. Grommet
- 14. Delivery pipe
- 15. Fuel return pipe
- 16. Solenoid valve assembly
- 17. EGR valve
- 18. Gasket

REMOVAL AND INSTALLATION <SOHC-MPI for PAJERO io>




9EN0998

Removal steps

- 1. Vacuum hose and pipe assembly
- 2. Throttle body
- ▶C◀ 3. Gasket
- 4. Vacuum hose
- ▶B◀ 5. Fuel hose
- 6. Fuel pressure regulator
- 7. O-ring
- 8. Delivery pipe and injector

- ▶A◀ 9. Insulator
- 10. Insulator
- 11. Injector
- 12. O-ring
- 13. Grommet
- 14. Delivery pipe
- 15. Fuel return pipe
- 16. Solenoid valve assembly

REMOVAL AND INSTALLATION <DOHC>



9EN0632

Removal steps

- ▶C▶ 1. Vacuum pipe assembly
- ▶C▶ 2. Throttle body assembly
- ▶C▶ 3. Gasket
- ▶C▶ 4. Throttle body stay (MIVEC)
- ▶B▶ 5. Vacuum hose
- ▶B▶ 6. Fuel hose
- ▶B▶ 7. Fuel pressure regulator
- ▶B▶ 8. O-ring
- ▶B▶ 9. Delivery pipe and injector

- ▶A▶ 10. Insulator
- ▶A▶ 11. Insulator
- ▶A▶ 12. Injector
- ▶A▶ 13. O-ring
- ▶A▶ 14. Grommet
- ▶A▶ 15. Delivery pipe
- ▶A▶ 16. Fuel return pipe


INSTALLATION SERVICE POINTS**▶A◀ INJECTORS INSTALLATION**

- (1) Apply a small amount of new engine oil to the O-ring.

Caution

Be sure not to let engine oil get into the delivery pipe.

- (2) While turning the injector to the left and right, install it to the delivery pipe.
- (3) Check that the injector turns smoothly. If it does not turn smoothly, the O-ring may be trapped. Remove the injector and check the O-ring for damage, and then re-insert it into the delivery pipe and check once again.
- (4) Check that the clearance between the injector connector and the delivery pipe is uniform (A = B).


**▶B◀ FUEL PRESSURE REGULATOR INSTALLATION**

- (1) Apply a small amount of new engine oil to the O-ring. Insert the fuel pressure regulator into the delivery pipe being careful not to damage the O-ring.

Caution


Be sure not to let engine oil get into the delivery pipe.

- (2) Check that the fuel pressure regulator turns smoothly. If it does not turn smoothly, the O-ring may be trapped. Remove the fuel pressure regulator and check the O-ring for damage, and then re-insert it into the delivery pipe and check once again.

**▶C◀ GASKET INSTALLATION**

- (1) Position the projection as shown in the illustration.


11A-5-6 4G9 ENGINE (E-W) – Fuel and Emission Control System



11A-5a-2 4G9 ENGINE (E-W) – Throttle Body and EGR System (GDI)

REMOVAL AND INSTALLATION

<From 2001 model for CARISMA, From 2001 model for SPACE STAR, GALANT>




9EN1058

Removal steps

- B◄
1. Intake manifold stay (For GALANT)
 2. Water hose
 3. Water hose
 4. Water hose
 5. Throttle body stay
 6. Throttle body

- A◄
7. Throttle body gasket
 8. Ignition harness
 9. Water hose
 10. EGR valve
 11. EGR valve support
 12. Gasket

REMOVAL AND INSTALLATION <For PAJERO io>



9EN0956




Removal steps

1. Water hose
2. Water hose
3. Water hose
4. Water hose
5. Water hose
6. Water hose clamp
7. Water pipe
8. Water pipe

- | | |
|----|---|
| ▶◀ | <ol style="list-style-type: none"> 9. Throttle body 10. Throttle body gasket 11. EGR valve 12. EGR valve gasket 13. EGR valve support 14. Gasket 15. Engine hanger |
|----|---|



INSTALLATION SERVICE POINTS

▶A◀ THROTTLE BODY GASKET




▶B◀ INTAKE MANIFOLD STAY INSTALLATION

- (1) Tighten the four bolts at the top and bottom of the stay handtight.
- (2) Check that the stay seating surface is in close contact with the bosses on the intake manifold and the cylinder block.
- (3) Tighten the four bolts to the specified torque.



6. INTAKE AND EXHAUST MANIFOLD

REMOVAL AND INSTALLATION <SOHC-CARBURETOR>




Removal steps

- ▶B◀ 1. Engine hanger
- ▶B◀ 2. Intake manifold stay
- ▶B◀ 3. Intake manifold
- ▶B◀ 4. Intake manifold gasket
- ▶B◀ 5. Oil level gauge
- ▶B◀ 6. Oil level gauge guide

- ▶A◀ 7. O-ring
- ▶A◀ 8. Exhaust manifold cover
- ▶A◀ 9. Engine hanger
- ▶A◀ 10. Exhaust manifold bracket A
- ▶A◀ 11. Exhaust manifold bracket B
- ▶A◀ 12. Exhaust manifold
- ▶A◀ 13. Exhaust manifold gasket

REMOVAL AND INSTALLATION <SOHC-MPI (Up to 2000 model)>



9EN0819


Removal steps

1. Engine hanger
2. Intake manifold stay
3. Intake manifold
4. Intake manifold gasket
5. Oil level gauge
6. Oil level gauge guide

7. O-ring
8. Exhaust manifold cover
9. Engine hanger
- ▶A◀ 10. Exhaust manifold bracket A
- ▶A◀ 11. Exhaust manifold bracket B
12. Exhaust manifold
13. Exhaust manifold gasket

Intentionally blank

REMOVAL AND INSTALLATION <DOHC>




9EN0576

Removal steps

1. Engine hanger
2. Intake manifold stay
3. Intake manifold
4. Intake manifold gasket
5. Oil level gauge
6. Oil level gauge guide


7. O-ring
8. Engine hanger
- ▶A▶ 9. Exhaust manifold bracket A
- ▶A▶ 10. Exhaust manifold bracket B
11. Exhaust manifold
12. Exhaust manifold gasket



INSTALLATION SERVICE POINT

▶A◀ EXHAUST MANIFOLD INSTALLATION

- (1) Install temporarily the exhaust manifold brackets A and B as shown in the illustration.
- (2) Check that both brackets are in close contact with the bosses, and then tighten fully the bracket mounting bolts.




▶B◀ INTAKE MANIFOLD STAY INSTALLATION

- (1) Install the intake manifold stay with its "UP" mark directed toward the intake manifold.

6a. INTAKE MANIFOLD (GDI)

REMOVAL AND INSTALLATION <Up to 2000 model for CARISMA, 1999 model for SPACE STAR, SPACE RUNNER>




9EN0890

Removal steps

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Air by-pass hose
(Up to 1998 model for CARISMA,
SPACE RUNNER) 2. Vacuum pipe and hose 3. Bracket 4. Solenoid valve | <ol style="list-style-type: none"> 5. Connector bracket 6. Accelerator cable bracket 7. Vacuum hose 8. Vacuum pipe 9. Intake manifold 10. Intake manifold gasket |
|--|--|

REMOVAL AND INSTALLATION

<From 2001 model for CARISMA, From 2001 model for SPACE STAR, GALANT>



9EN1062


Removal steps

- 1. Vacuum pipe and hose
- 2. Purge hose
- 3. Solenoid valve

- 4. Vacuum pipe
- 5. Intake manifold

Intentionally blank

REMOVAL AND INSTALLATION <For SPACE RUNNER>




9EN0983

Removal steps

- | | |
|-------------------------|------------------------------|
| 1. Air by-pass hose | 6. Accelerator cable bracket |
| 2. Vacuum pipe and hose | 7. Vacuum hose |
| 3. Bracket | 8. Vacuum pipe |
| 4. Solenoid valve | 9. Intake manifold |
| 5. Connector bracket | 10. Intake manifold gasket |

REMOVAL AND INSTALLATION <For PAJERO io>




9EN0995

Removal steps

1. P.C.V. hose
2. Vacuum pipe and hose
3. Solenoid valve
4. Fuel pump protector
5. Connector bracket

- | | |
|----|----------------------------|
| ▶◀ | 6. Branch tube |
| | 7. Gasket |
| | 8. Intake manifold stay |
| | 9. Intake manifold |
| | 10. Intake manifold gasket |




INSTALLATION SERVICE POINT

▶◀ INTAKE MANIFOLD STAY INSTALLATION

- (1) Check to ensure that the intake manifold stay is in close contact with the intake manifold and the cylinder block before tightening the respective mounting bolts to the specified torque.

6b. EXHAUST MANIFOLD (GDI)

REMOVAL AND INSTALLATION <For CARISMA, SPACE STAR, SPACE RUNNER>




9EN0882

Removal steps

1. Oil level gauge
2. Oil level gauge guide
3. O-ring
4. Exhaust manifold cover
5. Engine hanger
6. Exhaust manifold bracket A
7. Exhaust manifold bracket B
8. Exhaust manifold
9. Exhaust manifold gasket



REMOVAL AND INSTALLATION <For GALANT>




9EN1063

Removal steps

1. Oil level gauge
2. Oil level gauge guide
3. O-ring
4. Oxygen sensor
5. Engine hanger
6. Exhaust manifold cover
7. Exhaust manifold bracket B
8. Heat protector
9. Exhaust manifold
10. Exhaust manifold gasket
11. Exhaust manifold bracket A


Intentionally blank

REMOVAL AND INSTALLATION <For PAJERO io>


**Removal steps**

1. Exhaust manifold cover
2. Engine hanger
3. Exhaust manifold bracket
4. Exhaust manifold
5. Exhaust manifold gasket




**INSTALLATION SERVICE POINTS****▶A◀ EXHAUST MANIFOLD BRACKET INSTALLATION**


- (1) Slide the washers over the bolts with the chamfered side toward the bolt.



- (2) Install temporarily the exhaust manifold brackets A and B as shown in the illustration.
- (3) Check that both brackets are in close contact with the bosses, and then tighten fully the bracket mounting bolts.

**▶B◀ EXHAUST MANIFOLD BRACKET INSTALLATION**


- (1) The washers must be installed with the shear-drooped side toward the bolts.



- (2) Temporarily install the exhaust manifold bracket as shown in the illustration.
- (3) Verify that the bracket is brought into close contact with the boss on the exhaust manifold, then tighten the bolts to the specified torque.

6c. INJECTOR AND FUEL PUMP ASSEMBLY (GDI)

REMOVAL AND INSTALLATION <Up to 2000 model for CARISMA, 1999 model for SPACE STAR, SPACE RUNNER>



9EN0885


Removal steps

- | | | | |
|-----|----------------------------------|-----|--------------------------------|
| | 1. Fuel hose | | 20. Fuel pressure sensor |
| | 2. Fuel low pressure pipe | | 21. O-ring |
| | 3. O-ring | | 22. Backup ring |
| | 4. Fuel nipple | ►D◄ | 23. Pump camshaft case |
| | 5. O-ring | | 24. O-ring |
| | 6. Clamp | | 25. O-ring |
| ►F◄ | 7. Fuel feed pipe | ►C◄ | 26. Harness bracket |
| | 8. Backup ring | | 27. Injector harness |
| | 9. O-ring | | 28. Washer |
| ►F◄ | 10. Backup ring | | 29. Injector holder |
| | 11. Fuel pump | ►B◄ | 30. Delivery pipe and injector |
| | 12. O-ring | | 31. Insulator |
| | 13. Harness bracket | | 32. Injector gasket |
| | 14. Fuel return pipe | | 33. Injector |
| | 15. Backup ring | ►A◄ | 34. Corrugated washer |
| | 16. O-ring | ►A◄ | 35. Backup ring |
| | 17. Backup ring | ►A◄ | 36. O-ring |
| ►E◄ | 18. Fuel high pressure regulator | ►A◄ | 37. Backup ring |
| | 19. Flange | | 38. Delivery pipe |

Intentionally blank

11A-6C-2 4G9 ENGINE (E-W) – Injector and Fuel Pump Assembly (GDI)


REMOVAL AND INSTALLATION <For PAJERO io>



9EN0962

Removal steps

- | | | | |
|-----|----------------------|-----|----------------------------------|
| | 1. Injector harness | | |
| | 2. Fuel hose | | |
| | 3. Fuel hose | | |
| | 4. Fuel hose | | |
| | 5. Fuel pipe | | |
| | 6. Fuel nipple | | |
| | 7. O-ring | | |
| | 8. Fuel nipple | | |
| | 9. O-ring | | |
| ▶F◀ | 10. Fuel feed pipe | ▶E◀ | 20. Fuel high pressure regulator |
| | 11. Backup ring | ▶D◀ | 21. Fuel pressure sensor |
| | 12. O-ring | | 22. Backup ring |
| | 13. Backup ring | | 23. O-ring |
| ▶F◀ | 14. Fuel pump | | 24. Spacer |
| | 15. O-ring | | 25. washer |
| | 16. Fuel return pipe | | 26. Injector holder |
| | 17. Backup ring | ▶B◀ | 27. Delivery pipe and injector |
| | 18. O-ring | | 28. Insulator |
| | 19. Backup ring | | 29. Injector gasket |
| | | ▶A◀ | 30. Corrugated washer |
| | | ▶A◀ | 31. Backup ring |
| | | ▶A◀ | 32. O-ring |
| | | ▶A◀ | 33. Backup ring |
| | | | 34. Injector |
| | | | 35. Delivery pipe |



INSTALLATION SERVICE POINTS



▶A◀ BACKUP RING / O-RING / CORRUGATED WASHER INSTALLATION

- (1) Attach the backup rings and O-ring to the injector. The thicker backup ring must be so installed that the inside cut surface is directed as shown in the illustration.

- (2) Coat the corrugated washer with white vaseline and install it to the injector as shown.

Caution

Always replace the corrugated washer with new one. Reused corrugated washer can cause fuel or gas leaks.





▶B◀ DELIVERY PIPE AND INJECTOR ASSEMBLY INSTALLATION


- (1) Lubricate O-ring in the injector with spindle oil or gasoline.
- (2) Insert the injector straight into the injector mounting hole in the delivery pipe.
- (3) Turn the injector clockwise and counterclockwise. If it does not rotate smoothly, remove it to check for damaged O-ring. Damaged O-ring must be replaced with a new one. Reinstall the injector and check for smooth rotation again.
- (4) Align the mating mark on the injector with that on the delivery pipe.
- (5) Install the injector gaskets and insulators on the cylinder head. The insulator can drop off easily. Apply vaseline to it before installation so that it may be held in position.
- (6) Install the delivery pipe and injector assembly onto the cylinder head, then tighten the fasteners temporarily.
- (7) Install the injector holders and the washers to the assembly and tighten the fasteners to the specified torque.

Caution



Strictly observe the specified torque.



11A-6c-4 4G9 ENGINE (E-W) – Injector and Fuel Pump Assembly (GDI)



- (8) Tighten the fasteners of the delivery pipe and injector assembly to the specified torque in the order given in the illustration.




►C◄ PUMP CAMSHAFT CASE INSTALLATION

- (1) Apply small amount of engine oil to the O-ring (larger one) on the case.
- (2) Install the pump camshaft case onto the cylinder head while aligning the coupling keys of the case with the grooves in the rear end face of the camshaft.

NOTE


The coupling keys and the grooves at the camshaft rear end are offset with respect to the camshaft center.

- (3) Tighten the case mounting bolts to the specified torque.



►D◄ FUEL PRESSURE SENSOR INSTALLATION


- (1) Install the backup ring to the fuel pressure sensor with its inside cut surface in the illustrated direction.
- (2) Install the fuel pressure sensor straight into the fuel pressure regulator with labeled surface upward.
- (3) Tighten the fuel pressure sensor mounting bolt to the specified torque.



►E◄ FUEL HIGH PRESSURE REGULATOR INSTALLATION


- (1) Install the fuel high pressure regulator on the pump camshaft case <for CARISMA> or onto the spacer <for PAJERO io> and tighten the 3 bolts lightly (with somewhat larger torque than fingertight). Tightening to the specification is to be carried out in the step described in ►F◄.

- (2) Fit the backup rings and the O-ring on both ends of the fuel return pipe. Note that the larger backup ring must be installed with the inside cut surface in the direction shown in the illustration.
- (3) Lubricate the O-rings on both ends of the pipe with spindle oil or gasoline.
- (4) Insert the fuel return pipe ends straight in the respective mounting holes of the pressure regulator and the delivery pipe. Be sure to insert the pipe fully to the stop using care not to twist it.
- (5) Tighten the bolts at both ends of the pipe to the specified torque.



►F◀ FUEL PUMP / FUEL FEED PIPE INSTALLATION


- (1) Insert the fuel pump into the mounting hole in the pump camshaft case <for CARISMA> or in the cylinder head <for PAJERO io>, and secure it temporarily with 4 bolts (tighten somewhat with a larger torque than fingertight).
- (2) Fit the backup rings and the O-ring on both ends of the feed pipe. Note that the larger backup ring must be installed with the inside cut surface in the direction shown in the illustration.
- (3) Lubricate the O-rings on both ends of the pipe with spindle oil or gasoline.
- (4) Insert the fuel feed pipe ends straight in the respective mounting holes of the fuel and the delivery pipe. Be sure to insert the pipe fully to the stop using care not to twist it.
- (5) Tighten the bolts at ends of the pipe to the specified torque.
- (6) Tighten the mounting bolts of the fuel pressure regulator to the specified torque.




- (7) Using a torque wrench having the minimum scale of 0.5 Nm, tighten the fuel pump mounting bolts in the following order.
 - 1) Tighten the bolts to 5 Nm in the order given in the illustration.
 - 2) Tighten the bolts to 17 Nm in the order given in the illustration. The torque variation among 4 bolts must be within 2 Nm.

Caution

Strictly observe the specified tightening torque. Deviation from the specification can cause problems such as leakage or the like.




11A-6c-6 4G9 ENGINE (E-W) – Injector and Fuel Pump Assembly (GDI)




►G◄ O-RING / FUEL PUMP INSTALLATION

(1) Apply engine oil to the roller of the fuel pump and O-ring.



(2) Insert the fuel pump into the mounting hole in the cylinder head and lightly tighten the four bolts.




(3) Using a torque wrench (minimum graduations of 0.5 Nm), follow these steps to tighten the fuel pump mounting bolts.

- 1) Tighten the bolts to 4.9 Nm in the order shown.
- 2) Tighten the bolts to 17 ± 2 Nm in the order shown. Variations in torque among the four bolts should be within 2 Nm.


Caution

Strictly observe the tightening order. A leak and other problem could result if the torque specifications and torquing order are not met.




►H◄ O-RING / BACKUP RING / FUEL PIPE INSTALLATION

- (1) Fit the backup rings and O-ring to both ends of the fuel pipe. Mount the backup ring (thicker one) so that its inner cut surface faces in the direction shown.
- (2) Coat the O-rings on both ends of the pipe with spindle oil or gasoline.
- (3) Insert the fuel pipe straight into the mounting hole in the delivery pipe. Insert it all the way into the hole, ensuring that it does not twist.
- (4) Tighten the bolts on both ends of the fuel pipe to the specified torque.



▶◀ O-RING / BACKUP RING / FUEL PRESSURE SENSOR INSTALLATION


- (1) Fit the backup ring to the fuel pressure sensor so that its inner cut surface faces in the direction shown.



- (2) Being attentive to the shape of the connector and label surface of the fuel pressure sensor, install the fuel pressure sensor in the direction shown.

7. WATER PUMP AND WATER HOSE

REMOVAL AND INSTALLATION <SOHC>




9EN0577

Removal steps

- 1. Water hose
(Except carburetor engines)
- 2. Water hose
- ▶G◀ 3. Engine coolant temperature sensor
- ▶F◀ 4. Engine coolant temperature gauge unit
- ▶E◀ 5. Water outlet fitting
- 6. Water inlet fitting

- ▶D◀ 7. Thermostat
- ▶C◀ 8. Thermostat case
- ▶B◀ 9. O-ring
- ▶B◀ 10. Water inlet pipe
- ▶B◀ 11. O-ring
- ▶A◀ 12. Water pump

REMOVAL AND INSTALLATION <DOHC>




9EN0578

Removal steps

- ▶G▶ 1. Water hose A (Except GDI engine)
- ▶F▶ 2. Water hose B (Except GDI engine)
- ▶E▶ 3. Engine coolant temperature sensor
- ▶E▶ 4. Engine coolant temperature gauge unit
- ▶E▶ 5. Water outlet fitting (Except GALANT)

- ▶D▶ 6. Water inlet fitting
- ▶C▶ 7. Thermostat
- ▶B▶ 8. Thermostat case
- ▶B▶ 9. O-ring
- ▶B▶ 10. Water inlet pipe
- ▶B▶ 11. O-ring
- ▶A▶ 12. Water pump

REMOVAL AND INSTALLATION <DOHC-GDI for PAJERO io>




9EN0965

Removal steps

- ▶G◀ 1. Engine coolant temperature sensor
- ▶F◀ 2. Engine coolant temperature gauge unit
- ▶I◀ 3. Water fitting
- ▶E◀ 4. Water outlet fitting
- ▶D◀ 5. Water inlet fitting
- ▶D◀ 6. Thermostat

- ▶H◀ 7. Water by-pass fitting
- ▶B◀ 8. Water pipe
- ▶B◀ 9. O-ring
- ▶C◀ 10. Thermostat case
- ▶B◀ 11. Water pipe
- ▶B◀ 12. O-ring
- ▶A◀ 13. Water pump



INSTALLATION SERVICE POINTS

▶A◀ WATER PUMP INSTALLATION

- (1) Apply 3 mm diameter of Form-In-Place Gasket (FIPG) to the location shown in the illustration.

Specified sealant:


Mitsubishi Genuine Part No.MD970389 or equivalent

▶B◀ WATER INLET PIPE <SOHC, DOHC> / WATER PIPE <DOHC-GDI for PAJERO io> / O-RING INSTALLATION

- (1) Replace the O-ring of the water inlet pipe <SOHC, DOHC> or water pipe <DOHC-GDI for PAJERO io>, and then apply water to the O-ring to make installation easy.

Caution

1. Never apply any oil or grease to the O-ring.
2. Secure the water pipe after the thermostat case has been installed.




▶C◀ THERMOSTAT CASE INSTALLATION

- (1) Apply 3 mm diameter of Form-In-Place Gasket (FIPG) to the location shown in the illustration.


Specified sealant:

Mitsubishi Genuine Part No.MD970389 or equivalent



▶D◀ THERMOSTAT INSTALLATION

- (1) Install the thermostat so that the jiggle valve is facing straight up.








▶E◀ WATER OUTLET FITTING INSTALLATION

- (1) Apply 3 mm diameter of Form-In-Place Gasket (FIPG) to the location shown in the illustration.

Specified sealant:

Mitsubishi Genuine Part No.MD970389 or equivalent



▶◀ ENGINE COOLANT TEMPERATURE GAUGE UNIT INSTALLATION

- (1) Apply the specified sealant to the threads.

Specified sealant:

3M ATD Part No.8660 or equivalent

▶◀ ENGINE COOLANT TEMPERATURE SENSOR INSTALLATION

- (1) When reusing the sensor, apply the specified sealant to the threads.

Specified sealant:

3M Nut Locking Part No.4171 or equivalent

▶◀ WATER BY-PASS FITTING INSTALLATION

- (1) Apply 3 mm diameter of Form-In-Place Gasket (FIPG) to the location shown in the illustration.

Specified sealant:

Mitsubishi Genuine Part No.MD970389 or equivalent.

▶◀ WATER FITTING INSTALLATION


- (1) Apply 3 mm diameter of Form-In-Place Gasket (FIPG) to the location shown in the illustration.

Specified sealant:

Mitsubishi Genuine Part No.MD970389 or equivalent.

8. ROCKER ARMS AND CAMSHAFTS

REMOVAL AND INSTALLATION <SOHC (Up to 2000 model)>



Apply engine oil to all moving parts before installation.


9EN0580

Removal steps

1. Breather hose
2. P.C.V. hose
3. Oil filler cap
4. Rocker cover
5. Rocker cover gasket
6. Oil seal
7. Oil seal
8. Rocker arm spring
9. Rocker arms and rocker arm shaft IN
10. Rocker arms and rocker arm shaft EX

11. Rocker arm B
12. Rocker arm A
- ▶B◀▶A◀ 13. Rocker arm shaft
- ▶B◀▶A◀ 14. Adjusting screw
15. Nut
- ▶B◀▶A◀ 16. Rocker arm C
- ▶B◀▶A◀ 17. Rocker arm shaft
- ▶B◀▶A◀ 18. Adjusting screw
19. Nut
20. Camshaft

REMOVAL AND INSTALLATION <SOHC (From 2001 model)>




9EN1064

Removal steps


- 1. Breather hose
- 2. P.C.V. hose
- 3. Oil filler cap
- 4. Rocker cover
- 5. Rocker cover gasket
- 6. Oil seal
- 7. Oil seal
- 8. Rocker arm spring
- 9. Rocker arms and rocker arm shaft IN
- 10. Rocker arms and rocker arm shaft EX

- 11. Rocker arm B
- 12. Rocker arm A
- 13. Rocker arm shaft
- 14. Lash adjuster
- 15. Rocker arm C
- 16. Rocker arm shaft
- 17. Lash adjuster
- 18. Camshaft



Intentionally blank

REMOVAL AND INSTALLATION <DOHC>




Apply engine oil to all moving parts before installation.

9EN0999

Removal steps

- | | | | |
|-----|--------------------------|-----|----------------------|
| ▶K◀ | 1. Breather hose | ▶H◀ | 10. Oil seal |
| | 2. P.C.V. hose | ▶G◀ | 11. Bearing cap |
| | 3. P.C.V. valve | ▶G◀ | 12. Intake camshaft |
| | 4. P.C.V. valve gasket | ▶A◀ | 13. Exhaust camshaft |
| | 5. Oil filler cap | ▶F◀ | 14. Rocker arm |
| | 6. Rocker cover | | 15. Lash adjuster |
| | 7. Rocker cover gasket A | | |
| ▶J◀ | 8. Rocker cover gasket B | | |
| | 9. Semi-circular packing | | |

REMOVAL AND INSTALLATION <DOHC-GDI for CARISMA (Up to 2000 model), SPACE STAR (1999 model), SPACE RUNNER>




Apply engine oil to all moving parts before installation.

Removal steps

- 1. Breather hose
- 2. P.C.V. hose
- 3. P.C.V. valve
- 4. P.C.V. valve gasket
- 5. Oil filler cap
- 6. Rocker cover
- 7. Rocker cover gasket

- 8. Oil seal
- 9. Beam camshaft cap
- 10. Gasket
- 11. Intake camshaft
- 12. Exhaust camshaft
- 13. Rocker arm
- 14. Lash adjuster

REMOVAL AND INSTALLATION <DOHC-GDI for CARISMA (From 2001 model), SPACE STAR (From 2001 model), GALANT>



8EN104B


Removal steps

- 1. P.C.V. hose
- 2. P.C.V. valve
- 3. P.C.V. valve gasket
- 4. Breather hose
- 5. Oil filler cap
- 6. Rocker cover, intake
- 7. Rocker cover gasket, intake
- 8. Rocker cover, exhaust
- 9. Rocker cover gasket, exhaust

- 10. Oil seal
- 11. Circular packing
- 12. Beam camshaft cap
- 13. Beam camshaft cap gasket
- 14. Intake camshaft
- 15. Exhaust camshaft
- 16. Rocker arm
- 17. Lash adjuster

Intentionally blank

REMOVAL AND INSTALLATION <DOHC-GDI for PAJERO io>



Apply engine oil to all moving parts before installation.

Removal steps

- 1. Breather hose
- 2. P.C.V. valve
- 3. P.C.V. valve gasket
- 4. Oil filler cap
- 5. Rocker cover
- 6. Rocker cover gasket
- 7. Oil seal
- 8. Thrust case


- 9. O-ring
- 10. Beam camshaft cap
- 11. Gasket
- 12. Intake camshaft
- 13. Exhaust camshaft
- 14. Rocker arm
- 15. Lash adjuster

REMOVAL SERVICE POINT**◀A▶ LASH ADJUSTER REMOVAL****Caution**

- If the lash adjuster is re-used, clean the lash adjuster. (Refer to 11A-8-10.)

INSTALLATION SERVICE POINTS**▶A◀ ADJUSTING SCREW INSTALLATION**

- (1) Install provisionally the screw to the rocker arm. Insert it so that the end of the screw is flush with the edge of the rocker arm or projects slightly (1 mm or less).


**▶B◀ ROCKER ARM SHAFT INSTALLATION**

- (1) Place the end with the larger chamfered side toward the timing belt side.

NOTE

The rocker arm shaft for intake valves has eight oil holes.


- (2) Install the shaft with the oil holes toward the cylinder head.

**▶C◀ ROCKER ARMS AND ROCKER ARM SHAFT INSTALLATION**


- (1) Move the rocker arms in the directions shown in the illustration before tightening the rocker arm shaft bolts.


NOTE

Move the rocker arms until they touch the rocker arm shaft mounting bosses on the cylinder head.

**▶D◀ ROCKER ARM SPRING INSTALLATION**

- (1) Insert the rocker arm spring at an angle to the spark plug guide and then install it so that it is at a right angle to the guide.






▶E◀ OIL SEAL INSTALLATION

▶F◀ LASH ADJUSTER INSTALLATION

Caution

- If the lash adjuster is re-used, clean the lash adjuster. (Refer to 11A-8-10.)

- (1) Fit the lash adjuster onto the cylinder head using care not to allow diesel fuel to spill out.




▶G◀ CAMSHAFT INSTALLATION

- (1) Apply engine oil to the camshaft journals and cam before installing the camshaft. Use care not to confuse the intake camshaft with the exhaust camshaft.


NOTE

The rear end of the intake camshaft is provided with a 4 mm-wide slit.



▶H◀ BEARING CAP INSTALLATION


- (1) Locate the camshaft dowel pins as illustrated.



- (2) Apply sealant to the locations shown in the illustration.

Specified sealant:

3M ATD Part No. 8660 or equivalent



- (3) The bearing caps No. 2 through No. 5 are of the same shape. Before they are installed, check the cap number and the intake and exhaust identification marks.

Identification mark (stamped on front and No. 2 through No. 5 bearing caps)




L: Intake side

R: Exhaust side

- (4) Make sure that the rocker arms are installed in the specified locations.

▶◀ BEAM CAMSHAFT CAP INSTALLATION


- (1) Locate the camshaft dowel pin as illustrated.




- (2) Turn the crankshaft anticlockwise a quarter turn (90°).
- (3) Apply a 3 mm thick continuous bead of sealant to the bottom surface of the beam camshaft cap along the groove.

Specified sealant:

Mitsubishi Genuine Part No. MD970389 or equivalent






- (4) Apply sealant to the illustrated position of the cylinder head upper surface.

Specified sealant:


**Mitsubishi Genuine Part No. MD970389
or equivalent**



- (5) Install the beam camshaft cap before the sealant applied becomes dry and hard.

- (6) Tighten the bolts to the specified torque in the order shown in the illustration.


M6 bolt 11Nm
M8 bolt 21Nm



Caution


The M8 bolts plated green cannot be reused. Always replace such bolts with M8 bolts finished by glossy plating which are available separately.


The M8 bolt finished by glossy plating is reusable; if the caps have already been assembled with such bolts, then reassemble the caps using them.



- (7) Install the camshaft oil seal (use the special tool) and the thrust case <DOHC-GDI for PAJERO io> before the sealant applied becomes dry and hard.


- (8) Wipe off squeezed out excess sealant from the circumference of the beam camshaft cap.





▶J◀ SEALANT APPLICATION ON SEMI-CIRCULAR PACKING


Specified sealant: 3M ATD Part No.8660 or equivalent



▶K◀ SEALANT APPLICATION ON ROCKER COVER

(1) Apply sealant to the areas indicated in the illustration.

Specified sealant: 3M ATD Part No.8660 or equivalent



VALVE CLEARANCE ADJUSTMENT


Adjust the valve clearance by the following procedure.

Adjustment values (when engine is cold):

Intake valve: 0.09 mm

Exhaust valve: 0.20 mm

(1) Turn the crankshaft in the clockwise direction to align the camshaft sprocket timing marks and to set the No.1 cylinder to the compression top dead centre position.




(2) The valve clearances at the places indicated by arrows in the illustration can be adjusted.


(3) Use a thickness gauge to adjust the clearance between the ends of the valve stems and the adjusting screws.

(4) Hold the adjusting screws with a screwdriver so that they do not turn, and then tighten the lock nuts.

(5) Turn the crankshaft once in the clockwise direction to set the No.4 cylinder to the compression top dead centre position.



(6) Adjust the valve clearances indicated by arrows in the illustration by the same procedure as in steps (3) and (4) above.



INSPECTION CAMSHAFT

(1) Measure the cam height.

		Standard value mm	Limit mm
Intake side	4G92-SOHC*1	37.34	36.84
	4G92-SOHC*2	37.78	37.28
	4G92-SOHC*3	36.92	36.42
	4G93-SOHC	37.53	37.03
	4G93-DOHC	35.49	34.99
	4G93-DOHC-GDI	35.49	34.99
	4G94-DOHC-GDI	35.49	34.99
Exhaust side	4G92-SOHC*1	37.83	37.33
	4G92-SOHC*2	37.83	37.33
	4G92-SOHC*3	36.70	36.65
	4G93-SOHC	37.64	37.14
	4G93-DOHC	35.20	34.70
	4G93-DOHC-GDI	34.73	34.23
	4G94-DOHC-GDI	34.91	34.41

*1: LANCER for Europe and CARISMA for Europe

*2: LANCER for general export and CARISMA for 6B model


*3: LANCER for Europe (from 2001 model) and CARISMA for Europe (from 2001 model)


LASH ADJUSTER (SOHC)

Caution

1. The lash adjusters are precision-engineered mechanisms. Do not allow them to become contaminated by dirt or other foreign substances.
2. Do not attempt to disassemble the lash adjusters.
3. Use only fresh diesel fuel to clean the lash adjusters.

- (1) Prepare three containers and approximately five liters of diesel fuel. Into each container, pour enough diesel fuel to completely cover a lash adjuster when it is standing upright. Then, perform the following steps with each lash adjuster.






- (2) Place the lash adjuster in container A and clean its outside surface.

NOTE

Use a nylon brush if deposits are hard to remove.




- (3) While gently pushing down the internal steel ball using special tool MD998442, move the plunger through 5 to 10 strokes until it slides smoothly. In addition to eliminating stiffness in the plunger, this operation will remove dirty oil.

Caution


The steel ball spring is extremely weak, so the lash adjuster's functionality may be lost if the air bleed wire is pushed in hard.

NOTE

If the plunger remains stiff or the mechanism appears otherwise abnormal, replace the lash adjuster.




- (4) Remove the lash adjuster from the container. Then, push down the steel ball gently and push the plunger to eliminate diesel fuel from the pressure chamber.




- (5) Place the lash adjuster in container B. Then, gently push down the internal steel ball using special tool MD998442 and move the plunger through 5 to 10 strokes until it slides smoothly. This operation will clean the lash adjuster's pressure chamber.

Caution

The steel ball spring is extremely weak, so the lash adjuster's functionality may be lost if the air bleed wire is pushed in hard.




- (6) Remove the lash adjuster from the container. Then, push down the steel ball gently and push the plunger to eliminate diesel fuel from the pressure chamber.




- (7) Place the lash adjuster in container C. Then, gently push down the internal steel ball using special tool MD998442.

Caution

Do not use container C for cleaning. If cleaning is performed in container C, foreign matter could enter the pressure chamber when chamber is filled with diesel fuel.



- (8) Stand the lash adjuster with its plunger at the top, then push the plunger downward firmly until it moves through its greatest possible stroke. Return the plunger slowly, then release the steel ball and allow the pressure chamber to fill with diesel fuel.



- (9) Remove the lash adjuster from the container, then stand the lash adjuster with its plunger at the top. Push the plunger firmly and check that it does not move. Also, check that the lash adjuster's height matches that of a new lash adjuster.

NOTE


If lash adjuster contracts, perform the operations (7) through (9) again to fill it with diesel fuel completely. Replace the lash adjuster if it still contracts after performing these steps.

- (10) Stand the lash adjuster upright to prevent diesel fuel from spilling out. Do not allow the lash adjuster to become contaminated by dirt or other foreign matter. Fit the lash adjuster onto the engine as soon as possible.


(DOHC)

Caution

1. The lash adjusters are precision-engineered mechanisms. Do not allow them to become contaminated by dirt or other foreign substances.
2. Do not attempt to disassemble the lash adjusters.
3. Use only fresh diesel fuel to clean the lash adjusters.




- (1) Prepare three containers and approximately five liters of diesel fuel. Into each container, pour enough diesel fuel to completely cover a lash adjuster when it is standing upright. Then, perform the following steps with each lash adjuster.



- (2) Place the lash adjuster in container A and clean its outside surface.

NOTE

Use a nylon brush if deposits are hard to remove.




- (3) While gently pushing down the internal steel ball using special tool MD998442, move the plunger through 5 to 10 strokes until it slides smoothly. In addition to eliminating stiffness in the plunger, this operation will remove dirty oil.

Caution

The steel ball spring is extremely weak, so the lash adjuster's functionality may be lost if the air bleed wire is pushed in hard.

NOTE


If the plunger remains stiff or the mechanism appears otherwise abnormal, replace the lash adjuster.



- (4) Remove the lash adjuster from the container. Then, push down the steel ball gently and push the plunger to eliminate diesel fuel from the pressure chamber.

Caution


Make sure the oil hole in the side of the body is pointing toward container A. Do not point the oil hole at yourself or other people.



- (5) Place the lash adjuster in container B. Then, gently push down the internal steel ball using special tool MD998442 and move the plunger through 5 to 10 strokes until it slides smoothly. This operation will clean the lash adjuster's pressure chamber.

Caution


The steel ball spring is extremely weak, so the lash adjuster's functionality may be lost if the air bleed wire is pushed in hard.



- (6) Remove the lash adjuster from the container. Then, push down the steel ball gently and push the plunger to eliminate diesel fuel from the pressure chamber.

Caution


Make sure the oil hole in the side of the body is pointing toward container B. Do not point the oil hole at yourself or other people.




- (7) Place the lash adjuster in container C. Then, gently push down the internal steel ball using special tool MD998442.

Caution

Do not use container C for cleaning. If cleaning is performed in container C, foreign matter could enter the pressure chamber when chamber is filled with diesel fuel.



- (8) Stand the lash adjuster with its plunger at the top, then push the plunger downward firmly until it moves through its greatest possible stroke. Return the plunger slowly, then release the steel ball and allow the pressure chamber to fill with diesel fuel.



- (9) Remove the lash adjuster from the container, then stand the lash adjuster with its plunger at the top. Push the plunger firmly and check that it does not move. Also, check that the lash adjuster's height matches that of a new lash adjuster.


NOTE

If lash adjuster contracts, perform the operations (7) through (9) again to fill it with diesel fuel completely. Replace the lash adjuster if it still contracts after performing these steps.

- (10) Stand the lash adjuster upright to prevent diesel fuel from spilling out. Do not allow the lash adjuster to become contaminated by dirt or other foreign matter. Fit the lash adjuster onto the engine as soon as possible.

8a. ROCKER COVER AND CAMSHAFTS (MIVEC)

REMOVAL AND INSTALLATION



Removal steps

- 1. Breather hose
- 2. PCV hose
- 3. Oil filler cap
- ▶G◀ 4. Rocker cover
- 5. Rocker cover gasket
- 6. Oil seal
- ▶F◀ ▶E◀ 7. Oil seal
- 8. Oil control valve



- 9. Arm spring holder
- ▶D◀ ▶D◀ 10. Camshaft bearing cap
- ▶C◀ 11. Arm spring
- ▶B◀ 12. Camshaft
- ▶A◀ 13. Camshaft holder
- 14. Semi-circular packing

11A-8a-2 4G9 ENGINE (E-W) – Rocker Cover and Camshafts (MIVEC)

INSPECTION



1. OIL CONTROL VALVE

- (1) Connect a 12VDC power supply between terminals (1) and (2) of the oil control valve and check if the valve operates smoothly.




2. CAMSHAFT

- (1) Measure the cam heights. If the specified limit is exceeded, replace the camshaft.



Unit: mm

	Standard value	Limit
4G92 DOHC-MIVEC		
Intake A	36.41	35.91
Intake B	33.58	33.08
Exhaust A	35.83	35.33
Exhaust B	34.24	33.74




INSTALLATION SERVICE POINTS

▶A◀ SEMI-CIRCULAR PACKING INSTALLATION

- (1) Apply the specified sealant to the area shown.

Specified sealant:

3M ATD Part No. 8660 or equivalent.



▶B◀ CAMSHAFT HOLDER ASSEMBLY INSTALLATION


- (1) Apply the specified sealant to the area shown.

Specified sealant:

3M ATD Part No. 8660 or equivalent

▶C◀ CAMSHAFT INSTALLATION

- (1) Ensure that the intake-side and exhaust-side camshafts are not reversed. The exhaust-side camshaft is longer and has a slot in its rear end.
- (2) Set the No. 1 piston at the top dead center and install the camshafts with their cams for No. 1 cylinder directed upward so that the No. 1 cylinder becomes the top dead center on the compression stroke.



▶D◀ CAMSHAFT BEARING CAP / CAMSHAFT HOLDER INSTALLATION

- (1) Confirm the identification mark on each bearing cap to install the cap in the correct position.

Identification mark

L1: Front bearing for exhaust camshaft


R1: Front bearing for intake camshaft

11A-8a-4 4G9 ENGINE (E-W) – Rocker Cover and Camshafts (MIVEC)

- (2) Apply the specified sealant to the front and rear camshaft bearing caps at the positions shown. Position the camshaft bearing caps and tighten their mounting bolts not numbered in the illustration. Then tighten the remaining (numbered) bolts in the order shown in the illustration to install the bearing caps and camshaft holder to the cylinder head.

Specified sealant:

3M ATD part No. 8660 or equivalent





9EN0316

►E◀ OIL CONTROL VALVE INSTALLATION


- (1) Apply the specified sealant to the area shown.

Specified sealant:

3M ATD Part No. 8660 or equivalent



►F◀ OIL SEAL INSTALLATION



►G◄ROCKER COVER INSTALLATION

Apply the specified sealant to the area' shown.


Specified sealant:

3M ATD part No. 8660 or equivalent


VALVE CLEARANCE ADJUSTMENT

Adjustment must be performed with the cylinder at the top dead center on the compression stroke.

- (1) Inserting the special tool between one of two adjusting screws and the valve and adjust the clearance.




- (2) Then adjust the other adjusting screw in the same way.




ROCKER ARM PISTON INSPECTION

- (1) Screw in the special tool to the rocker arm piston for high speed side rocker arm and check that the piston can be lifted up lightly by hand.



8b. ROCKER ARMS AND ROCKER SHAFT CAPS (MIVEC) REMOVAL AND INSTALLATION




Removal steps

1. Rocker shaft cap
2. Seal cap "A"
3. Seal cap "B"
4. Spring guide
5. Wave washer

- ▶▲ 6. Intake rocker arm assembly "A"
7. Spring guide
8. Wave washer
- ▶▲ 9. Exhaust rocker arm assembly "A"
10. Camshaft holder

11A-8b-2 4G9 ENGINE (E-W) – Rocker Arms and Rocker Shaft Caps (MIVEC)



INSTALLATION SERVICE POINT

▶A◀ROCKER ARM ASSEMBLY INSTALLATION

- (1) Install the rocker arm assemblies while checking the identification marks at the positions shown to ensure that the intake and exhaust sides are not reversed.


Identification marks:

E: Intake

I: Exhaust

9. CYLINDER HEAD AND VALVES

REMOVAL AND INSTALLATION <SOHC>




9EN0517

Removal steps

- | | | | |
|---------|---------------------------|---------|-------------------------|
| ◀A▶ ▶D▶ | 1. Cylinder head bolt | ◀C▶ ▶A▶ | 11. Intake valve |
| | 2. Cylinder head assembly | | 12. Valve stem seal |
| | 3. Cylinder head gasket | ◀C▶ ▶A▶ | 13. Valve spring seat |
| ◀B▶ ▶C▶ | 4. Retainer lock | | 14. Valve stem seal |
| | 5. Valve spring retainer | | 15. Valve spring seat |
| ▶B▶ | 6. Valve spring | | 16. Exhaust valve guide |
| | 7. Exhaust valve | | 17. Intake valve guide |
| ◀B▶ ▶C▶ | 8. Retainer lock | | 18. Exhaust valve seat |
| | 9. Valve spring retainer | | 19. Intake valve seat |
| ▶B▶ | 10. Valve spring | | 20. Cylinder head |

REMOVAL AND INSTALLATION <DOHC>




9EN0582

Removal steps

- ▶E◀ 1. Oil pressure switch
- ◀A▶ ▶D◀ 2. Cylinder head bolt
- 3. Cylinder head assembly
- ◀B▶ ▶C◀ 4. Cylinder head gasket
- 5. Retainer lock
- ▶B◀ 6. Valve spring retainer
- 7. Valve spring
- 8. Exhaust valve
- ◀B▶ ▶C◀ 9. Retainer lock
- 10. Valve spring retainer
- ▶B◀ 11. Valve spring

- ◀C▶ ▶A◀ 12. Intake valve
- 13. Valve stem seal
- 14. Valve spring seat
- ◀C▶ ▶A◀ 15. Valve stem seal
- 16. Valve spring seat
- 17. Exhaust valve guide
- 18. Intake valve guide
- 19. Exhaust valve seat
- 20. Intake valve seat
- 21. Cylinder head

REMOVAL AND INSTALLATION <DOHC-MIVEC>




Removal steps

- ◀A▶ ▶E▶ 1. Oil pressure switch
- ▶D▶ 2. Cylinder head bolt
- 3. Cylinder head assembly
- ▶B▶ ▶C▶ 4. Cylinder head gasket
- 5. Retainer lock
- 6. Valve spring retainer
- ▶B▶ 7. Valve spring
- ▶D▶ 8. Intake valve
- ▶B▶ ▶C▶ 9. Retainer lock
- 10. Valve spring retainer
- ▶B▶ 11. Valve spring

- ▶D▶ 12. Exhaust valve
- ▶C▶ ▶A▶ 13. Valve stem seal
- ▶C▶ ▶A▶ 14. Valve spring seat
- ▶A▶ 15. Valve stem seal
- ▶A▶ 16. Valve spring seat
- ▶A▶ 17. Intake valve guide
- ▶A▶ 18. Exhaust valve guide
- ▶A▶ 19. Intake valve seat
- ▶A▶ 20. Exhaust valve seat
- ▶A▶ 21. Cylinder head

REMOVAL AND INSTALLATION <DOHC-GDI>








9EN0775

Removal steps

- ◀A▶ ▶D▶ 1. Cylinder head bolt
- ▶B▶ ▶C▶ 2. Cylinder head assembly
- ▶B▶ ▶C▶ 3. Cylinder head gasket
- ▶B▶ ▶C▶ 4. Retainer lock
- ▶D▶ ▶B▶ 5. Valve spring retainer
- ▶B▶ ▶C▶ 6. Valve spring
- ▶D▶ ▶B▶ 7. Intake valve
- ▶B▶ ▶C▶ 8. Retainer lock
- ▶B▶ ▶C▶ 9. Valve spring retainer
- ▶B▶ ▶C▶ 10. Valve spring

- ▶D▶ ▶A▶ 11. Exhaust valve
- ▶C▶ ▶A▶ 12. Valve stem seal
- ▶C▶ ▶A▶ 13. Valve spring seat
- ▶C▶ ▶A▶ 14. Valve stem seal
- ▶C▶ ▶A▶ 15. Valve spring seat
- ▶C▶ ▶A▶ 16. Intake valve guide
- ▶C▶ ▶A▶ 17. Exhaust valve guide
- ▶C▶ ▶A▶ 18. Intake valve seat
- ▶C▶ ▶A▶ 19. Exhaust valve seat
- ▶C▶ ▶A▶ 20. Cylinder head

Intentionally blank




REMOVAL SERVICE POINTS

◀A▶ CYLINDER HEAD BOLT REMOVAL

- (1) Loosen the cylinder head bolts using the special tool.

◀B▶ RETAINER LOCK REMOVAL

- (1) Store the removed valves, springs and other parts, tagged to indicate their cylinder No. and location to aid reassembly.



◀C▶ VALVE STEM SEAL REMOVAL

◀D▶ VALVE HANDLING PRECAUTIONS

- (1) Sodium reacts violently with water or moisture generation^{MS} heat and liberating hydrogen. It must be handled with utmost care because otherwise the following dangerous conditions may result:
 Loss of eyesight if sodium gets in eyes.
 Burns if sodium contact skin.
 Fire hazard.
- (2) Handling of Sodium-filled Exhaust Valves
 Sodium-filled exhaust valves are not dangerous and may be handled in the same way as ordinary valves unless they are broken.
 Never try to break the valves and expose sodium to the air. When worn exhaust valves are to be discarded, have them disposed of by a salvage company equipped with special disposal system, notifying them that the valves contain sodium.
 Should the exhaust valves be broken, neutralize sodium using the method described below, and discard the valves in the same way as ordinary valves.
- (3) How to Neutralize Sodium
 Place a container filled with more than 10 liters of water in a well ventilated large space.
 Wear rubber gloves and goggles, and carefully take out broken valves from the cylinder head.
 Put a broken valve in the water-filled container and quickly get away from the container at least 2 or 3 m (6.6 or 10 ft.)

Caution

- Valves must be neutralized one at a time.
- Put a valve in the container only after sodium in the preceding one has completely reacted with water.

Keep fire away from the container during the neutralization. The resulting hydrogen gas is highly explosive.

When the reaction has finished (there is no more generation of hydrogen gas), take the valves out of the container with large tweezers or the like.

NOTE

The reaction occurs when water enters the cavity in the valve. Hydrogen gas may be trapped inside the valve, temporarily blocking the water passage. In such a case, wait until hydrogen gas is released and remaining sodium reacts with water.

After the neutralization of sodium, water in the container contains sodium hydroxide and is highly alkaline. The water solution should be disposed of according to local regulations.

Caution



- Do not let the solution contact the eyes or the skin.
- Should it get in the eyes, immediately flush them with clean water thoroughly, and receive medical attention. When it contacts the skin, wash with ample amounts of clean water.


INSTALLATION SERVICE POINTS**▶◀ VALVE STEM SEAL INSTALLATION**

- (1) Install the valve spring seat.
- (2) Use the special tool to install the valve stem seal. Improper installation could result oil leaking past the valve guide.

Caution


Do not reuse removed valve stem seals.








▶B◀ VALVE SPRING INSTALLATION

- (1) Install the valve spring with the painted end on the rocker arm side.



▶C◀ RETAINER LOCK INSTALLATION

- (1) The valve spring, if excessively compressed, causes the bottom end of retainer to be in contact with the stem seal, and damage it.




▶D◀ CYLINDER HEAD BOLT INSTALLATION


- (1) When installing the cylinder head bolts, check that the shank length of each bolt meets the limit. If the limit is exceeded, replace the bolts.

Limit: Max. 96.4 mm

- (2) Install the washers as illustrated.
- (3) Apply engine oil to the bolt threads and washers.



- (4) According to the tightening sequence, tighten the bolts to the specified torque 74 Nm.
- (5) Loosen all bolts fully.
- (6) Retighten the loosened bolts to a torque of 20 Nm in the specified tightening sequence.
- (7) Make paint marks on the cylinder head bolt heads and cylinder head.
- (8) Give a 90° turn to the cylinder head bolts in the specified tightening sequence.
- (9) Give another 90° turn to the cylinder head bolts and make sure that the paint mark on the head of each cylinder head bolt and that on the cylinder head are on the same straight line.



Caution

1. If the bolt is turned less than 90°, proper fastening performance may not be expected. When tightening the bolt, therefore, be careful to give a sufficient turn to it.
2. If the bolt is overtightened, loosen the bolt completely and then retighten it by repeating the tightening procedure from step (1).

▶◀ SEALANT APPLICATION TO OIL PRESSURE SWITCH


- (1) Apply sealant to the threads of the switch.


Specified sealant:

3M ATD Part No. 8660 or equivalent

Caution

Use care not to allow the sealant to plug the oil passage.





INSPECTION

CYLINDER HEAD

- (1) Check the cylinder head gasket surface for flatness by using a straightedge and thickness gauge.

Standard value: 0.03 mm

Limit: 0.2 mm

- (2) If the service limit is exceeded, correct to meet the specification.

Grinding limit:*0.2 mm

*Includes/combined with cylinder block grinding


Cylinder head height (Specification when new):

119.9 – 120.1 mm <SOHC>

131.9 – 132.1 mm <DOHC>

119.8 – 120.0 mm <DOHC-MIVEC>

131.9 – 132.1 mm <DOHC-GDI>




VALVE

- (1) Check the valve face for correct contact. If incorrect, reface using a valve refacer. Valve should make a uniform contact with the seat at the centre of valve face.
- (2) If the margin is smaller than the service limit, replace the valve.

		Standard value mm	Limit mm
Intake		1.0	0.5
Exhaust	SOHC	1.3	0.8
	DOHC	1.2	0.7

- (3) Measure the overall height of the valve. If the specified limit is exceeded, replace the valve.

		Standard value mm	Limit mm
Intake	SOHC	110.15	109.65
	DOHC	104.19	103.69
	DOHC-MIVEC	115.63	115.13
	DOHC-GDI	104.19	103.69
Exhaust	SOHC	113.70	113.20
	DOHC	103.87	103.37
	DOHC-MIVEC	115.63	115.13
	DOHC-GDI	103.87	103.37

**VALVE SPRING**


- (1) Measure the valve spring's free height. If the measurement is less than specified, replace the spring.

	Standard value mm	Limit mm
SOHC (Except from 2001 model vehicles for Europe)	50.9	49.9
SOHC (From 2001 model vehicles for Europe)	49.5	48.5
DOHC	45.0	44.0
DOHC-MIVEC	51.5	50.5
DOHC-GDI	44.8	43.8

- (2) Measure the squareness of the spring. If the measurement exceeds the specified limit, replace the spring.

Standard value: 2° or less

Limit: 4°

**VALVE SEAT**

- (1) Assemble the valve, then measure the valve stem projection between the end of the valve stem and the spring seating surface. If the measurement exceeds the specified limit, replace the valve seat.

		Standard value mm	Limit mm
Intake	SOHC	49.30	49.80
	DOHC	46.70	47.20
	DOHC-MIVEC	57.85	58.35
	DOHC-GDI	46.65	47.15
Exhaust	SOHC	49.35	49.85
	DOHC	46.65	47.15
	DOHC-MIVEC	58.13	58.63
	DOHC-GDI	46.70	47.20

VALVE GUIDE

- (1) Measure the clearance between the valve guide and valve stem. If the limit is exceeded, replace the valve guide or valve, or both.

Standard value:

Intake: 0.02 – 0.05 mm

Exhaust: 0.05 – 0.09 mm


<SOHC, DOHC, DOHC-MIVEC, DOHC-GDI for CARISMA, SPACE STAR, SPACE RUNNER, GALANT>


0.04 – 0.06 mm <DOHC-GDI for PAJERO io>

Limit:


Intake: 0.10 mm

Exhaust: 0.15 mm



**VALVE SEAT RECONDITIONING PROCEDURE**

- (1) Before correcting the valve seat, check the clearance between the valve guide and valve. If necessary, replace the valve and/or valve guide.
- (2) Using the appropriate special tool or seat grinder, correct the valve seat to achieve the specified seat width and angle.
- (3) After correcting the valve seat, lap the valve and valve seat using lapping compound. Then, check the valve stem projection (refer to VALVE SEAT in INSPECTION).

**VALVE SEAT REPLACEMENT PROCEDURE**

- (1) Cut the valve seat to be replaced from the inside to thin the wall thickness. Then, remove the valve seat.
- (2) Rebore the valve seat hole in the cylinder head to a selected oversize valve seat diameter.

Intake valve seat hole diameter

0.3 O.S. <SOHC>: 31.80 – 31.83 mm

<DOHC>: 34.30 – 34.33 mm

0.6 O.S. <SOHC>: 32.10 – 32.13 mm

<DOHC>: 34.60 – 34.63 mm


Exhaust valve seat hole diameter

0.3 O.S. <SOHC>: 29.30 – 29.32 mm

<DOHC>: 30.80 – 30.83 mm

0.6 O.S. <SOHC>: 29.60 – 29.62 mm

<DOHC>: 31.10 – 31.13 mm



- (3) Before fitting the valve seat, either heat the cylinder head up to approximately 250°C or cool the valve seat in liquid nitrogen, to prevent the cylinder head bore from galling.
- (4) Correct the valve seat to the specified width and angle.

VALVE GUIDE REPLACEMENT

- (1) Force the valve guide out toward the cylinder block using a press.
- (2) Machine the valve guide hole in the cylinder head to the size of the oversize valve guide to be installed.

Caution


Do not use the valve guide of the same size as the removed one.

Valve guide hole diameters in cylinder head

0.05 O.S.: 11.05 – 11.07 mm

0.25 O.S.: 11.25 – 11.27 mm

0.50 O.S.: 11.50 – 11.52 mm




- (3) Press-fit the valve guide until it protrude specified value (SOHC: 14 mm, DOHC: 19 mm) as shown in the illustration.

Caution

1. Press the valve guide from the cylinder head top surface.
 2. Valve guide for intake valve and that for exhaust valve are different in length. (45.5 mm for intake valve; 50.5 mm for exhaust valve)
- (4) After the valve guide has been installed, insert a new valve to check for smooth sliding motion.

10. FRONT CASE AND OIL PUMP

REMOVAL AND INSTALLATION <SOHC>



Apply engine oil to all moving parts before installation.


9EN0519

Removal steps

- ▶F◀ 1. Oil pressure switch
- ▶E◀ 2. Oil filter
- ▶A▶▶D◀ 3. Drain plug
- ▶A▶▶D◀ 4. Drain plug gasket
- ▶A▶▶D◀ 5. Oil pan
- ▶A▶▶D◀ 6. Oil screen
- ▶A▶▶D◀ 7. Oil screen gasket
- ▶A▶▶D◀ 8. Relief plug

- ▶C▶▶B◀ 9. Relief spring
- ▶C▶▶B◀ 10. Relief plunger
- ▶C▶▶B◀ 11. Oil seal
- ▶C▶▶B◀ 12. Oil pump case
- ▶C▶▶B◀ 13. O-ring
- ▶C▶▶B◀ 14. Oil pump case cover
- ▶C▶▶A◀▶A◀ 15. Outer rotor
- ▶C▶▶A◀▶A◀ 16. Inner rotor

REMOVAL AND INSTALLATION <DOHC>



Apply engine oil to all moving parts before installation.


9EN0888

Removal steps

- | | | |
|-------------|---|-------------------------|
| ▶F◀ | 1. Oil pressure switch | 10. Relief plug |
| ▶E◀ | 2. Oil filter | 11. Relief spring |
| | 3. Drain plug | 12. Relief plunger |
| | 4. Drain plug gasket | ▶C◀ ▶B◀ |
| | 5. Baffle plate <For CARISMA, SPACE STAR, GALANT> | 13. Oil seal |
| ▶B◀ ▶D◀ ▶D◀ | 6. Upper oil pan | 14. Oil pump case |
| | 7. Lower oil pan | 15. O-ring |
| | 8. Oil screen | ▶C◀ ▶A◀ ▶A◀ |
| | 9. Oil screen gasket | 16. Oil pump case cover |
| | | 17. Outer rotor |
| | | 18. Inner rotor |

REMOVAL AND INSTALLATION <DOHC-GDI for PAJERO io>

Apply engine oil to all moving parts before installation.




9EN0975

Removal steps

- ▶F◀ 1. Oil pressure switch
- ▶E◀ 2. Oil filter
- 3. Drain plug
- 4. Drain plug gasket
- 5. Cover
- ◀B▶ ▶D◀ 6. Upper oil pan
- ▶D◀ 7. Lower oil pan
- 8. Oil screen
- 9. Oil screen gasket

- 10. Relief plug
- 11. Relief spring
- 12. Relief plunger
- ◀C▶ ▶B◀ 13. Oil seal
- ▶B◀ 14. Oil pump case
- 15. O-ring
- 16. Oil pump case cover
- ◀C▶ ▶A◀ 17. Outer rotor
- ▶A◀ 18. Inner rotor



REMOVAL SERVICE POINTS

◀A▶ OIL PAN REMOVAL


- (1) Knock in the special tool deeply between the oil pan and the cylinder block.
- (2) Hitting the side of the special tool, slide the special tool along the oil pan to remove the oil pan.

◀B▶ REMOVAL OF UPPER OIL PAN

- (1) At first remove the bolt (Length: 121 mm <DOHC, DOHC-GDI for CARISMA>, 116 mm <DOHC-GDI for PAJERO io>) which is nearest to flywheel, and the remove the other bolts.


Caution

Never use the special tool (oil pan remover), etc.



◀C▶ OUTER ROTOR/INNER ROTOR REMOVAL

- (1) Make alignment dots on the outer and inner rotors for reference in reassembly.



INSTALLATION SERVICE POINTS


▶A◀ INNER ROTOR/OUTER ROTOR INSTALLATION


- (1) Apply engine oil to the rotors. Then, install the rotors ensuring that the alignment dots made at disassembly are properly aligned.

▶B◀ SEALANT APPLICATION TO OIL PUMP CASE

Specified sealant:



Mitsubishi Genuine Part No. MD970389 or equivalent





►C◄ **CRANKSHAFT FRONT OIL SEAL INSTALLATION**

Using the special tool, knock the oil seal into the oil pump case.





►D◄ **OIL PAN/UPPER OIL PAN/LOWER OIL PAN INSTALLATION**


- (1) Remove all the remaining gasket from the mating surfaces using a scraper or a wire brush.
- (2) Apply a 4 mm diameter bead of sealant to the oil pan flange.
See "Form-In-Place Gasket" in "SPECIFICATIONS".

Specified sealant:


Mitsubishi Genuine Part No. MD970389 or equivalent

- (3) Install the oil pan within 15 minutes after applying the sealant.





- (4) Tighten the lower oil pan mounting bolts in the sequence shown in the illustration.



►E◀ OIL FILTER INSTALLATION

- (1) Clean the filter installation surface of the cylinder block.
- (2) Apply engine oil to the O-ring of the oil filter.
- (3) Screw in the oil filter until its O-ring comes in contact with the base. Then tighten one more turn.

►F◀ SEALANT APPLICATION TO OIL PRESSURE SWITCH


- (1) Apply sealant to the threads of the switch.

Specified sealant:

3M ATD Part No. 8660 or equivalent

Caution

Use care not to allow the sealant to plug the oil passage.




INSPECTION


11300730026

OIL PUMP


- (1) Check the tip clearance.

Standard value: 0.06 – 0.18 mm





- (2) Check the side clearance.
Standard value: 0.04 – 0.10 mm




- (3) Check the body clearance.
Standard value: 0.10 – 0.18 mm
Limit: 0.35 mm

11. PISTON AND CONNECTING ROD

REMOVAL AND INSTALLATION

Lubricate all internal parts with engine oil during re-assembly.




Z9EN0043

Removal steps

- ◀A▶ G 1. Nut
- F 2. Connecting rod cap
- E 3. Connecting rod bearing
- D 4. Piston and connecting rod
- E 5. Connecting rod bearing
- C 6. Piston ring No. 1

- ▶B▶ C 7. Piston ring No. 2
- B 8. Oil ring
- A 9. Piston pin
- 10. Piston
- 11. Connecting rod
- 12. Bolt



REMOVAL SERVICE POINTS


◀A▶ CONNECTING ROD CAP REMOVAL

- (1) Mark the cylinder number on the side of the connecting rod big end for correct reassembly.

◀B▶ PISTON PIN REMOVAL

Piston pin setting tool (MD998780) consists of the parts shown in the illustration at left.


To remove the piston pin, Guide D (MB991659) is also used in combination with the Piston pin setting tool.



- (1) Insert the Push Rod (special tool) into the piston from the side on which the front mark is stamped in the piston head, and attach the guide D to the push rod end.
- (2) Place the piston and connecting rod assembly on the Piston Pin Setting Base (special tool) with the front mark facing upward.
- (3) Using a press, remove the piston pin.

NOTE

Keep the disassembled pistons, piston pins and connecting rods in order according to the cylinder number.





INSTALLATION SERVICE POINTS


▶A◀ PISTON PIN INSTALLATION

- (1) Measure the following dimensions of the piston, piston pin and connecting rod.
 - A: Piston pin insertion hole length
 - B: Distance between piston bosses
 - C: Piston pin length
 - D: Connecting rod small end width
- (2) Calculate the following formula by substituting the measured value.

$$L = ((A - C) - (B - D))/2$$
- (3) Insert the Push Rod (special tool) into the piston pin and attach the guide A to the push rod end.
- (4) Assemble the connecting rod in the piston with their front marks facing the same direction.
- (5) Apply engine oil to the entire periphery of the piston pin.
- (6) Insert the piston pin, push rod and guide A assembly having assembled in step (3) from the guide A side into the piston pin hole on the front marked side.





- (7) Screw the guide B into the guide A until the gap between both guides amounts to the value L obtained in step (2) plus 3 mm.



- (8) Place the piston and connecting rod assembly onto the piston setting base with the front marks directed upward.
- (9) Press-fit the piston pin using a press. If the press-fitting force required is less than the standard value, replace the piston and piston pin set or/and the connecting rod.

Standard value: 4,500 – 14,700 N



▶B◀ OIL RING INSTALLATION

- (1) Fit the oil ring spacer into the piston ring groove. Install the upper side rail, and then install the lower side rail.

NOTE

1. The side rails and spacer may be installed in either direction.
2. New spacer and side rail are painted with the following identification colour according to the size.


Size	Identification colour
Standard size	None
0.50 mm O.S.	Blue
1.00 mm O.S.	Yellow

3. To install the side rail, first fit one end of the rail into the piston groove, then press the remaining portion into position by finger as shown in the illustration.

Caution

Do not use piston ring expander when installing side rail. Use of piston ring expander to expand the side rail end gap can break the side rail, unlike other piston rings.

- (3) Make sure that the side rails move smoothly in either direction.




▶C◀ PISTON RING NO.2/PISTON RING NO.1 INSTALLATION

- (1) Using piston ring expander, install the piston rings with their side having identification marks facing up.

Identification mark:


- No.1 ring: T**
- No.2 ring: 2T**



NOTE


The piston ring is stamped with the following size mark.

Size	Size mark
Standard size	None
0.50 mm O.S.	50
1.00 mm O.S.	100



▶D◀ PISTON AND CONNECTING ROD INSTALLATION


- (1) Liberally coat engine oil on the circumference of the piston, piston ring and oil ring.
- (2) Arrange the piston ring and oil ring gaps (side rail and spacer) as shown in the illustration.
- (3) Face the front mark (arrow) on the top of the piston toward the camshaft sprocket.



- (4) Using a suitable piston ring compressor tool, insert the piston and connecting rod assembly into the cylinder block.

Caution


Do not strike the piston into the cylinder block because the piston ring or crank pin will be damaged.




▶E◀ CONNECTING ROD BEARING INSTALLATION

- (1) When the bearings are to be replaced, select correct ones according to the identification marks stamped in the crankshaft.

Crankshaft	Connecting rod bearing	
Pin O.D. identification mark	Identification mark (service part)	Identification colour (Line production part)
1	S1	Brown
2	S2	Black
3	S3	Green






►F◄ CONNECTING ROD CAP INSTALLATION

- (1) Mate the correct bearing cap with the correct connecting rod by checking with the alignment marks marked during disassembly. If a new connecting rod has no alignment mark, position the notches for locking the bearing on the same side.

- (2) Check if the thrust clearance in the connecting rod big end is correct.

Standard value: 0.10 – 0.25 mm

Limit: 0.4 mm




►G◄ CONNECTING ROD CAP NUT INSTALLATION

Caution

If the cylinder head has been installed before installing the connecting rod cap nut, be sure to remove the spark plugs.


- (1) Since the connecting rod cap bolts and nuts are torqued using the plastic area tightening method, the bolts should be examined BEFORE reuse. If the bolt threads are "necked down", the bolt should be replaced.
Necking can be checked by running a nut with fingers to the full length of the bolt threads. If the nut does not run down smoothly, the bolt should be replaced.
- (2) Before installation of each nut, apply engine oil to the thread portion and bearing surface of the nut.
- (3) Install each nut to the bolt and tighten it with fingers. Then tighten the nuts alternately to install the cap properly.
- (4) Tighten the nuts to a torque of 20 Nm.



- (5) Make a paint mark on the head of each nut.
- (6) Make a paint mark on the bolt end at the position 90° to 100° from the paint mark made on the nut in the direction of tightening the nut.
- (7) Give a 90° to 100° turn to the nut and make sure that the paint mark on the nut and that on the bolt are in alignment.

Caution

1. If the nut is turned less than 90°, proper fastening performance may not be expected. When tightening the nut, therefore, be careful to give a sufficient turn to it.
2. If the nut is overtightened (exceeding 100°), loosen the nut completely and then retighten it by repeating the tightening procedure from step (1).



INSPECTION

11300850074

PISTON RING

- (1) Check the clearance between the piston ring and ring groove. If the limit is exceeded, replace the ring or piston, or both.

Standard value:

No.1: 0.03 – 0.07 mm

No.2: 0.02 – 0.06 mm

Limit:

No.1: 0.1 mm

No.2: 0.1 mm

Install the piston ring into the cylinder bore. Force the ring down with a piston, the piston crown being in contact with the ring, to correctly position it at right angles to the cylinder wall. Then, measure the end gap with a thickness gauge.

If the ring gap is excessive, replace the piston ring.

Standard value:

No.1: 0.25 – 0.40 mm (4G92, 4G93)

0.15 – 0.30 mm (4G94)

No.2: 0.40 – 0.55 mm

Oil:


SOHC: 0.20 – 0.60 mm


DOHC: 0.10 – 0.35 mm

Limit:

No.1, No.2: 0.8 mm

Oil: 1.0 mm






CRANKSHAFT PIN OIL CLEARANCE (PLASTIGAGE METHOD)

- (1) Remove oil from crankshaft pin and connecting rod bearing.
- (2) Cut the Plastigage to the same length as the width of bearing and place it on crankshaft pin in parallel with its axis.
- (3) Install the connecting rod cap carefully and tighten the bolts to specified torque.
- (4) Carefully remove the connecting rod cap.
- (5) Measure the width of the Plastigage at its widest part by using a scale printed on the Plastigage package.

Standard value: 0.02 – 0.05 mm

Limit: 0.1 mm

12. CRANKSHAFT, CYLINDER BLOCK, FLYWHEEL AND DRIVE PLATE REMOVAL AND INSTALLATION (MANUAL TRANSMISSION)



Removal steps




- | | | | |
|-----|------------------------------|---------|-------------------------------|
| ▶F◀ | 1. Flywheel bolt | ▶C◀ | 13. Bearing cap bolt |
| ▶F◀ | 2. Flywheel | ▶C◀ | 14. Bearing cap |
| ▶F◀ | 3. Flywheel bolt | ▶B◀ | 15. Crankshaft bearing, lower |
| | 4. Plate | | 16. Crankshaft |
| | 5. Adapter plate | ▶B◀ | 17. Thrust plate |
| | 6. Flywheel | ▶B◀ | 18. Crankshaft bearing, upper |
| | 7. Adapter plate | | 19. Knock sensor |
| | 8. Rear plate | | <DOHC-MIVEC> |
| | 9. Bell housing cover <SOHC> | ◀A▶ ▶A◀ | 20. Oil jet |
| ▶E◀ | 10. Rear oil seal case | | <DOHC-MIVEC> |
| ▶D◀ | 11. Oil seal | | 21. Cylinder block |
| | 12. Baffle plate | | |
| | <DOHC-MIVEC and DOHC-GDI> | | |

Caution

On the flexible wheel equipped engines, do not remove any of the bolts "A" of the flywheel shown in the illustration.

The balance of the flexible flywheel is adjusted in an assembled condition. Removing the bolt, therefore, can cause the flexible flywheel to be out of balance, giving damage to the flywheel.

REMOVAL AND INSTALLATION (AUTOMATIC TRANSMISSION)




Apply engine oil to all moving parts before installation.

9EN1066

Removal steps

- | | | | |
|-----|------------------------------|-----|-------------------------------|
| ▶F◀ | 1. Flywheel bolt | ▶C◀ | 12. Bearing cap bolt |
| | 2. Adapter plate | ▶C◀ | 13. Bearing cap |
| | 3. Drive plate | ▶B◀ | 14. Crankshaft bearing, lower |
| ▶F◀ | 4. Drive plate bolt | | 15. Crankshaft |
| | 5. Adapter plate | ▶B◀ | 16. Thrust plate |
| | 6. Drive plate | ▶B◀ | 17. Crankshaft bearing, upper |
| | 7. Rear plate | | 18. Knock sensor <DOHC-MIVEC> |
| | 8. Bell housing cover <SOHC> | ◀A▶ | ▶A◀ |
| ▶E◀ | 9. Rear oil seal case | | 19. Oil jet <DOHC-MIVEC> |
| ▶D◀ | 10. Oil seal | | 20. Cylinder block |
| | 11. Baffle plate | | |
- <DOHC-MIVEC and DOHC-GDI>

REMOVAL AND INSTALLATION <DOHC-GDI for PAJERO io>




Apply engine oil to all moving parts before installation.

9EN0977

Removal steps

- | | | | |
|-----|-----------------------------|-----|-------------------------------|
| ▶F◀ | 1. Flywheel bolt <M/T> | ▶C◀ | 10. Bearing cap bolt |
| ▶F◀ | 2. Flywheel <M/T> | ▶C◀ | 11. Bearing cap |
| ▶F◀ | 3. Drive plate bolt <A/T> | ▶B◀ | 12. Crankshaft bearing, lower |
| | 4. Adopter plate <A/T> | | 13. Crankshaft |
| | 5. Drive plate <A/T> | ▶B◀ | 14. Thrust plate |
| | 6. Crankshaft adaptor <A/T> | ▶B◀ | 15. Crankshaft bearing, upper |
| ▶E◀ | 7. Rear plate | | 16. Knock sensor |
| ▶D◀ | 8. Rear oil seal case | | 17. Cylinder block |
| | 9. Oil seal | | |




REMOVAL SERVICE POINT

◀A▶ OIL JET REMOVAL

- (1) Knock out the oil jets using an appropriate metal rod.

Caution


1. Be careful not to scratch the cylinder wall.
2. Do not reuse the removed oil jets.



INSTALLATION SERVICE POINTS

▶A◀ OIL JET INSTALLATION

- (1) Using a 4.5 mm diameter pin punch, drive in the oil jet to the crankshaft journal until it seats to the bottom.







▶B◀ CRANKSHAFT BEARING INSTALLATION

- (1) When the bearings are to be replaced, select correct ones and install them in the correct positions according to the identification marks stamped on the crankshaft and the top surface of the cylinder block.

Crankshaft journal	Cylinder block bearing bore	Crankshaft bearing	
		Identification mark (service parts)	Identification colour (Line production parts)
1	0	S1	Brown
	1	S2	Black
	2	S3	Green
2	0	S2	Black
	1	S3	Green
	2	S4	Yellow
3	0	S3	Green
	1	S4	Yellow
	2	S5	Pink*

*: Older bearings may be marked in red.




- (2) Install the bearings having an oil groove to the cylinder block.
- (3) Install the bearings having no oil groove on the bearing caps.
- (4) Install the thrust bearings at the No. 3 upper bearing with the grooved side towards the crank web.

►C◄ BEARING CAP/BEARING CAP BOLT INSTALLATION

- (1) Install the bearing caps so that their arrows are positioned on the time belt side.
- (2) When installing the bearing cap bolts, check that the shank length of each bolt meets the limit. If the limit is exceeded, replace the bolt.

Limit: max. 71.1 mm


- (3) Apply engine oil to the threaded portion and bearing surface of the bolt.
- (4) Tighten the bearing cap bolts to 25 Nm torque in the tightening sequence.



- (5) Make a paint mark on the head of each bolt.
- (6) Make a paint mark on the area around the bolt bearing surface at location 90° to 100° in the direction of tightening the bolt, as referenced from the paint mark on the bolt head.
- (7) Give a 90° to 100° turn to the bolts in the tightening sequence. Make sure that the paint mark on the bolt and that on the area around the bolt bearing surface are in alignment.

Caution


1. If the nut is turned less than 90°, proper fastening performance may not be expected. When tightening the nut, therefore, be careful to give a sufficient turn to it.
2. If the nut is overtightened (exceeding 100°), loosen the nut completely and then retighten it by repeating the tightening procedure from step (1).




- (8) After installing the bearing caps, make sure that the crankshaft turns smoothly and the end play is correct. If the end play exceeds the limit, replace crankshaft bearings.

Standard value: 0.05 – 0.25 mm

Limit: 0.4 mm




▶D◀ OIL SEAL INSTALLATION



▶E◀ SEALANT APPLICATION TO OIL SEAL CASE

Specified sealant:

Mitsubishi Genuine Part No. MD970389 or equivalent



►F◄ DRIVE PLATE BOLT/FLYWHEEL BOLT INSTALLATION

- (1) Remove all the remaining sealant from bolts and thread holes of crankshaft.
- (2) Apply engine oil to the flange of bolt.
- (3) Apply engine oil into the thread holes of crankshaft.
- (4) Apply specified sealant to the thread of bolts.

Specified sealant:


3M Nut Locking Part No. 4171 or equivalent

- (5) Tighten the bolts to specified torque.

INSPECTION

CRANKSHAFT JOURNAL OIL CLEARANCE (PLASTIGAUGE METHOD)


- (1) Remove oil from the crankshaft journal and the crankshaft bearing.
- (2) Install the crankshaft.
- (3) Cut the Plastigauge to the same length as the width of bearing and place it on the journal in parallel with its axis.



- (4) Install the crankshaft bearing cap carefully and tighten the bolts to the specified torque.
- (5) Carefully remove the crankshaft bearing cap.
- (6) Measure the width of the Plastigauge at its widest part by using a scale printed on the Plastigauge package.

Standard value: 0.02 – 0.04 mm

Limit: 0.1 mm



CYLINDER BLOCK

- (1) Using a straightedge and thickness gauge, check the block top surface for warpage. Make sure that the surface is free from gasket chips and other foreign matter.

Standard value: 0.05 mm or less

Limit: 0.1 mm

- (2) If the distortion is excessive, correct within the allowable limit or replace.

Grinding limit: 0.2 mm

The total thickness of the stock allowed to be removed from cylinder block and mating cylinder head 0.2 mm at maximum.


Cylinder block height (when new):


243.5 mm <4G92>

263.5 mm <4G93>

286.7 mm <4G94>

- (3) Check the cylinder walls for scratches and seizure. If defects are evident, correct (bored to oversize) or replace.





- (4) Using a cylinder gauge, measure the cylinder bore and cylindricity. If worn badly, correct the cylinder to an oversize and replace the piston and piston rings. Measure at the points shown in illustration.

Standard value:

Cylinder inner diameter:

4G92, 4G93 81.00 – 81.03 mm

4G94 81.50 – 81.53 mm

Out-of-roundness and taper of cylinder bore: 0.01 mm or less

BORING CYLINDER

- (1) Oversize pistons to be used should be determined on the basis of the largest bore cylinder.

Piston size identification

Size	Identification mark
0.50 mm O.S.	0.50
1.00 mm O.S.	1.00

NOTE

Size mark is stamped on the piston top.

- (2) Measure outside diameter of piston to be used. Measure it in thrust direction as shown.
- (3) Based on the measured piston O.D., calculate the boring finish dimension.

Boring finish dimension = Piston O.D. + (Clearance between piston O.D. and cylinder) – 0.02 mm (honing margin)

- (4) Bore all cylinders to the calculated boring finish dimension.

Caution

To prevent distortion that may result from temperature rise during honing, bore cylinders, in the order of No. 2, No. 4, No.1 and No. 3.


- (5) Hone to the final finish dimension (Piston O.D. + clearance between piston O.D. and cylinder.)
- (6) Check the clearance between piston and cylinder.

Clearance between piston and cylinder:

0.02 – 0.04 mm

NOTE

When boring cylinders, finish all of four cylinders to the same oversize. Do not bore only one cylinder to an oversize.




HYDRO-FLYWHEEL <DOHC-GDI for PAJERO io>

- (1) Check the rear side of the flywheel for color of the hatched area **A** in the illustration, and determine whether it is serviceable or not in accordance with the criteria given in the following table.


If judged unendurable for reuse, replace the flywheel assembly.

Color	Purple	Dark blue	Light blue	Gray
Judgment	Reusable	Not reusable		



- (2) Measure the play in the circumferential direction using the following procedure.
 (3) Turn the flywheel clockwise and anticlockwise to measure the distance over which the dowel pin moves freely.

Limit: 9 mm



- (4) Check the friction surface for runout in the following manner.

- (5) Apply a thrust force of approx. 98 N by hand on the flywheel to move it in the axial direction, and measure the runout at the dowel pin position. If the limit is exceeded, replace the flywheel assembly.

Limit: 0.75 mm

